



Security Gateway Manual

Netgate-4200

© Copyright 2026 Rubicon Communications LLC

Feb 06, 2026

CONTENTS

1	Out of the Box	2
2	How-To Guides	24
3	References	109



This Quick Start Guide covers the first time connection procedures for the Netgate® 4200 Desktop Firewall Appliance and will provide the information needed to keep the appliance up and running.


OUT OF THE BOX

1.1 Getting Started

The basic firewall configuration begins with connecting the Netgate® appliance to the Internet. The Netgate appliance should be unplugged at this time.

Connect one end of an Ethernet cable to the WAN port (shown in the *Input and Output Ports* section) of the Netgate appliance. The other end of the same cable should be inserted into a LAN port on the ISP Customer Premise Equipment (CPE) device, such as a cable or fiber router. If the CPE device provided by the ISP has multiple LAN ports, any LAN port should work in most circumstances.

Next, connect one end of a second Ethernet cable to the LAN port (shown in the *Input and Output Ports* section) of the Netgate appliance. Connect the other end to the computer.



1.1.1 What next?

To connect to the GUI and configure the firewall in a browser, continue on to [Initial Configuration](#).

To connect to the console and make adjustments before connecting to the GUI, see [Connecting to the USB Console](#).

Warning: The default IP Address on the LAN subnet on the Netgate firewall is 192.168.1.1/24. The same subnet **cannot** be used on both WAN and LAN, so if the default IP address on the ISP-supplied modem is also 192.168.1.1/24, **disconnect the WAN** interface until the LAN interface on the firewall has been renumbered to a different subnet (like 192.168.2.1/24) to avoid an IP Address conflict.

To change an interface IP address, choose option 2 from the [Console Menu](#) and walk through the steps to change it, or from the GUI, go through the Setup Wizard (opens at first boot, also found at **System > Setup Wizard**) and change the IP address on Step 5. Complete the Wizard and save the changes.

1.2 Initial Configuration

Plug the power cable into the power port (shown in the [Input and Output Ports](#) section) to turn on the Netgate® Firewall. Allow 4 or 5 minutes to boot up completely.

Warning: If the ISP Customer Premise Equipment (CPE) on WAN (e.g. Fiber or Cable Router) has a default IP Address of 192.168.1.1, disconnect the Ethernet cable from the **1** port on the Netgate 4200 Security Gateway before proceeding.

Change the default LAN IP Address of the device during a later step in the configuration to avoid having conflicting subnets on the WAN and LAN.

1.2.1 Connecting to the Web Interface (GUI)

1. From the computer, log into the web interface

Open a web browser (Google Chrome in this example) and enter 192.168.1.1 in the address bar. Press Enter.




Fig. 1: Enter the default LAN IP address in the browser

2. A warning message may appear. If this message or similar message is encountered, it is safe to proceed. Click the **Advanced** Button and then click **Proceed to 192.168.1.1 (unsafe)** to continue.
3. At the **Sign In** page, enter the default pfSense® Plus username and password and click **Next**.
 - Default Username: **admin**
 - Default Password: **pfsense**



Your connection is not private

Attackers might be trying to steal your information from **192.168.1.1** (for example, passwords, messages, or credit cards). [Learn more](#)

NET::ERR_CERT_AUTHORITY_INVALID



To get Chrome's highest level of security, [turn on enhanced protection](#)

[Hide advanced](#)

1

[Back to safety](#)

This server could not prove that it is **192.168.1.1**; its security certificate is not trusted by your computer's operating system. This may be caused by a misconfiguration or an attacker intercepting your connection.

[Proceed to 192.168.1.1 \(unsafe\)](#)

2

Fig. 2: Example certificate warning message

1.2.2 The Setup Wizard

This section steps through each page of the Setup Wizard to perform the initial configuration of the firewall. The wizard collects information one page at a time, but it does not make any changes to the firewall until the wizard is completed.

Tip: The wizard can be safely stopped at any time for those who wish to perform the configuration manually or restore an existing backup ([Backup and Restore](#)).

To stop the wizard, navigate away from the wizard pages by clicking the logo in the upper left of the page or by choosing an entry from one of the menus.

Note: Ignore the warning at the top of each wizard page about resetting the `admin` account password. One of the steps in the Setup Wizard is to change the default password, but the new password is not applied until the end of the wizard.

1. Click **Next** to start the **Setup Wizard**.




Fig. 3: Setup Wizard starting page

2. Click **Next** after reading the information on **Netgate Global Support**.
3. Use the following items as a guide to configure the options on the **General Information** page:

Hostname

Any desired hostname name can be entered to identify the firewall. For the purposes of this guide, the default hostname `pfsense` is used.

Domain

The domain name under which the firewall operates. The default `home.arpa` is used for the purposes of this tutorial.

DNS Servers

For purposes of this setup guide, use the Google public DNS servers (8.8.8.8 and 8.8.4.4).

Note: The firewall defaults to acting as a resolver and clients will not utilize these forwarding DNS servers. However, these servers give the firewall itself a way to ensure it has working DNS if resolving the default way does not work properly.

Wizard / pfSense Plus Setup / General Information

Step 2 of 9

General Information

On this screen the general pfSense Plus parameters will be set.

Hostname: pfSense
EXAMPLE: myserver

Domain: home.arpa
EXAMPLE: mydomain.com

The default behavior of the DNS Resolver will ignore manually configured DNS servers for client queries and query root DNS servers directly. To use the manually configured DNS servers below for client queries, visit Services > DNS Resolver and enable DNS Query Forwarding after completing the wizard.

Primary DNS Server: 8.8.8.8

Secondary DNS Server: 8.8.4.4

Override DNS:
Allow DNS servers to be overridden by DHCP/PPP on WAN

>> Next

Fig. 4: **General Information** page in the Setup Wizard

Type in the DNS Server information and Click **Next**.

4. Use the following information for the **Time Server Information** page:

Time Server Hostname

Use the default time server address. The default hostname is suitable for both IPv4 and IPv6 NTP clients.

Timezone

Select a geographically named time zone for the location of the firewall.

For this guide, the Timezone will be set to America/Chicago for US Central time.

Change the Timezone and click **Next**.

5. Use the following information for the **Configure WAN Interface** page:

The WAN interface is the external (public) IP address the firewall will use to communicate with the Internet.

DHCP is the default and is the most common type of WAN interface for home fiber and cable modems.




Fig. 5: **Time Server Information** page in the Setup Wizard

Default settings for the other items on this page should be acceptable for normal home users.

Default settings should be acceptable. Click **Next**.

6. Configuring LAN IP Address & Subnet Mask. The default LAN IP address of 192.168.1.1 and subnet mask of 24 is usually sufficient.

Tip: If the CPE on WAN (e.g. Fiber or Cable Modem) has a default IP Address of 192.168.1.1, the Ethernet cable should be disconnected from the **1** port on the Netgate 4200 Security Gateway before starting.

Change the default LAN IP Address of the device during this step in the configuration to avoid having conflicting subnets on the WAN and LAN.

7. Change the **Admin Password**. Enter the same new password in both fields.
8. Click **Reload** to save the configuration.
9. After a few seconds, a message will indicate the Setup Wizard has completed. To proceed to the pfSense® Plus dashboard, click **Finish**.

Note: This step of the wizard also contains several useful links to Netgate resources and methods of obtaining assistance with the product. Be sure to read through the items on this page before finishing the wizard.

1.2.3 Finishing Up

After completing or exiting the wizard, during the first time loading the **Dashboard** the firewall will display a notification modal dialog with the **Copyright and Trademark Notices**.

Read and click **Accept** to continue to the dashboard.

If the Ethernet cable was unplugged at the beginning of this configuration, reconnect it to the **1** port now.

This completes the basic configuration for the Netgate appliance.

The screenshot shows the 'Configure WAN Interface' page of the pfSense Plus Setup Wizard, Step 4 of 9. The page has a header 'Wizard / pfSense Plus Setup / Configure WAN Interface' and a question mark icon. A progress bar at the top indicates 'Step 4 of 9'. The main section is titled 'Configure WAN Interface' with a sub-section 'General configuration'. It includes fields for 'SelectedType' (set to 'DHCP'), 'MAC Address' (input field), 'MTU' (input field), and 'MSS' (input field). Each field has a descriptive tooltip below it.

Setting	Value	Description
SelectedType	DHCP	On this screen the Wide Area Network information will be configured.
MAC Address		This field can be used to modify ("spoof") the MAC address of the WAN interface (may be required with some cable connections). Enter a MAC address in the following format: xx:xx:xx:xx:xx:xx or leave blank.
MTU		Set the MTU of the WAN interface. If this field is left blank, an MTU of 1492 bytes for PPPoE and 1500 bytes for all other connection types will be assumed.
MSS		If a value is entered in this field, then MSS clamping for TCP connections to the value entered above minus 40 (TCP/IP header size) will be in effect. If this field is left blank, an MSS of 1492 bytes for PPPoE and 1500 bytes for all other connection types will be assumed. This should match the above MTU value in most all cases.

Fig. 6: **Configure WAN Interface** page in the Setup Wizard

1.3 pfSense Plus Software Overview

This page provides an overview of the pfSense® Plus dashboard and navigation. It also provides information on how to perform frequent tasks such as backing up the pfSense® Plus software and connecting to the Netgate firewall console.

1.3.1 The Dashboard

pfSense® Plus software is highly configurable, all of which can be done through the dashboard. This orientation will help to navigate and further configure the firewall.

Section 1

Important system information such as the model, Serial Number, and Netgate Device ID for this Netgate firewall.

Section 2

Identifies what version of pfSense® Plus software is installed, and if an update is available.

Section 3

Describes Netgate Service and Support.

Section 4

Shows the various menu headings. Each menu heading has drop-down options for a wide range of configuration choices.

Copyright and Trademark Notices.

Copyright® 2004-2016. Electric Sheep Fencing, LLC ("ESF"). All Rights Reserved.

Copyright® 2014-2023. Rubicon Communications, LLC d/b/a Netgate ("Netgate"). All Rights Reserved.

All logos, text, and content of ESF and/or Netgate, including underlying HTML code, designs, and graphics used and/or depicted herein are protected under United States and international copyright and trademark laws and treaties, and may not be used or reproduced without the prior express written permission of ESF and/or Netgate.

"pfSense" is a registered trademark of ESF, exclusively licensed to Netgate, and may not be used without the prior express written permission of ESF and/or Netgate. All other trademarks shown herein are owned by the respective companies or persons indicated.

pfSense® software is open source and distributed under the Apache 2.0 license. However, no commercial distribution of ESF and/or Netgate software is allowed without the prior written consent of ESF and/or Netgate.

ESF and/or Netgate make no warranty of any kind, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. ESF and/or Netgate shall not be liable for errors contained herein or for any direct, indirect, special, incidental or consequential damages in connection with the furnishing, performance, or use of any software, information, or material.

Restricted Rights Legend.

No part of ESF and/or Netgate's information or materials may be published, distributed, reproduced, publicly displayed, used to create derivative works, or translated to another language, without the prior written consent of ESF and/or Netgate. The information contained herein is subject to change without notice.

Use, duplication or disclosure by the U.S. Government may be subject to restrictions as set forth in subparagraph (c) (1) (ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 for DOD agencies, and subparagraphs (c) (1) and (c) (2) of the Commercial Computer Software Restricted Rights clause at FAR 52.227-19 for other agencies.

Regulatory/Export Compliance.

The export and re-export of software is controlled for export purposes by the U.S. Government. By accepting this software and/or documentation, Licensee agrees to comply with all U.S. and foreign export laws and regulations as they relate to software and related documentation. Licensee will not export or re-export outside the United States software or documentation, whether directly or indirectly, to any Prohibited Party and will not cause, approve or otherwise intentionally facilitate others in so doing. A Prohibited Party includes: a party in a U.S. embargoed country or country the United States has named as a supporter of international terrorism; a party involved in proliferation; a party identified by the U.S. Government as a Denied Party; a party named on the U.S. Government's Enemies List; a party prohibited from participation in export or re-export transactions by a U.S. Government General Order; a party listed by the U.S. Government's Office of Foreign Assets Control as ineligible to participate in transactions subject to U.S. jurisdiction; or any party that Licensee knows or has reason to know has violated or plans to violate U.S. or foreign export laws or regulations. Licensee shall ensure that each of its software users complies with U.S. and foreign export laws and regulations as they relate to software and related documentation.

Accept

Fig. 7: Copyright and Trademark Notices




Fig. 8: The pfSense® Plus Dashboard

1.3.2 Re-running the Setup Wizard

To re-run the Setup Wizard, navigate to **System > Setup Wizard**.

1.3.3 Backup and Restore

It is important to back up the firewall configuration prior to updating or making any configuration changes. From the menu at the top of the page, browse to **Diagnostics > Backup/Restore**.

Click **Download configuration as XML** and save a copy of the firewall configuration to the computer connected to the Netgate firewall.

This backup (or any backup) can be restored from the same screen by choosing the backed up file under **Restore Configuration**.

Note: Auto Config Backup is a built-in service located at **Services > Auto Config Backup**. This service will save up to 100 encrypted backup files automatically, any time a change to the configuration has been made. Visit the [Auto Config Backup](#) page for more information.




Fig. 9: Re-run the Setup Wizard




Fig. 10: Backup & Restore




Fig. 11: Click Download configuration as XML

1.3.4 Connecting to the Console

There are times when accessing the console is required. Perhaps GUI console access has been locked out, or the password has been lost or forgotten.

See also:

Connecting to the USB Console. Cable is required.

Tip: To learn more about getting the most out of a Netgate appliance, sign up for a [pfSense Plus Software Training](#) course or browse the extensive [Resource Library](#).

1.3.5 Updates

When a new version of pfSense Plus software is available, the device will indicate the availability of the new version on the System Information dashboard widget. Users can perform a manual check as well by visiting **System > Update**.

Users can initiate an upgrade from the **System > Update** page as needed.

For more information, see the [Upgrade Guide](#).

1.4 Input and Output Ports

1.4.1 Rear Side

The rear side of the Netgate 4200 contains several items of interest for connecting to and managing the device.

The items below are marked with circled numbers on figure *Rear side view of the Netgate 4200 Firewall Appliance*:




Fig. 12: Rear side view of the Netgate 4200 Firewall Appliance

Item	Description
1	Power Connector
2	ACPI Power Button (Protruding) - Graceful shutdown, hard power off (Hold 10s), power on
3	Reset Button (Recessed) - Used when performing the <i>Factory Reset Procedure</i> .
4	Serial Console (USB or RJ45)
5	Rear <i>Status LEDs</i>
6	<i>Networking Ports</i>

Power Connector (1)

The Power connector is 12VDC with threaded locking connector. Power consumption is approximately 13W when idle.

Power Button (2)

The upper protruding Power Button behaves the same as a typical ACPI power button.

If the device is powered on and running, pressing the button immediately performs a graceful shutdown and the system enters a standby state.

If the system is in a powered off or standby state, pressing the power button immediately powers on the device and starts the boot process.

If the system is unresponsive, holding in the power button for 10 seconds will forcefully power off the device. Press the power button again to turn it back on.

Reset Button (3)

The lower recessed Reset Button is used to perform the *Factory Reset Procedure*.

Pressing and immediately releasing the button has no effect, it does not perform a hardware reset.

See *Factory Reset Procedure* for details on how to use the button to perform a factory reset.

Serial Console Port (4)

Clients can access the serial console using the [USB Micro-B \(5-pin\)](#) serial adapter port and a compatible USB cable or via the [RJ45](#) “Cisco” style port with a separate cable and USB serial adapter or client hardware port.

Note: Only one type of console connection will work at a time and the RJ45 console connection has priority. If both ports are connected only the RJ45 console port will function.

Note: The serial console in the OS is a memory mapped serial port and not a traditional COM port. pfSense® Plus automatically detects and uses the correct console type for this device.

Note: The RJ45 Serial Console port is only for use with the Serial Console. It cannot be used for any other purpose.

Status LEDs (5)

The rear status LEDs show the same output as the status LEDs on the front of the unit. See [Status LEDs](#) for information on interpreting the meaning of different LED states.

Networking Ports (6)

This group of four ports are the network interfaces. They are explained in detail in the next section, [Networking Ports](#).

Networking Ports

The section on the rear of the device numbered **6** in [Rear side view of the Netgate 4200 Firewall Appliance](#) contains the network interfaces. These ports are labeled **1** through **4** on the device.

Label	Assigned Name	Device Name	Type	Speed
1	PORT1WAN	igc3	RJ-45	2.5 Gbps
2	PORT2LAN	igc2	RJ-45	2.5 Gbps
3	PORT3	igc1	RJ-45	2.5 Gbps
4	PORT4	igc0	RJ-45	2.5 Gbps

Note: The igc(4) network interfaces on this device **do not** implement fixed speed operation. These interfaces emulate a speed/duplex choice by limiting the values offered during autonegotiation to the speed/duplex value selected in the GUI.

When connecting different devices to these interfaces the peer should typically be set to autonegotiate, not to a specific speed or duplex value. The exception to this is if the peer interface has the same limitation, in which case both peers should select the same negotiation speed.

1.4.2 Front Side

The front of the device has [Status LEDs](#) as well as an access panel for future expansion uses.



Fig. 13: Front view of the Netgate 4200 Firewall Appliance

1.4.3 Right Side



Fig. 14: Right side view of the Netgate 4200 Firewall Appliance

The right side panel of the device (when facing the front) contains:

#	Description	Purpose
1	USB 3.0 Port	Connect USB devices

USB Ports

USB ports on the device can be used for a variety of purposes.

The primary use for the USB ports is to install or reinstall the operating system on the device. Beyond that, there are numerous USB devices which can expand the base functionality of the hardware, including some implemented by add-on packages. For example, UPS/Battery Backups, Cellular modems, GPS units, and storage devices. Though the operating system also includes drivers for wired and wireless USB network devices, these are not ideal and should be avoided.

1.4.4 Status LEDs

The Netgate 4200 has two sets of status LEDs: One on the front of the device and one on the rear. The status LEDs on the front are horizontal while the LEDs on the rear are arranged vertically. Though the placement is different, both sets are labeled consistently.

LED Patterns

Description	LED Pattern
Standby	Circle pulsing orange
Power On Self Test	Circle solid orange
Boot in Process	Diamond flashing blue
Boot Completed/Ready	Diamond solid blue
Upgrade Available	Square solid purple
Upgrade in Progress	All rapidly flash green
Triggering Reset	Circle, Square, then Diamond solid red (<i>Factory Reset Procedure</i>)
Reset In Progress	All rapidly flash red (<i>Factory Reset Procedure</i>)



Fig. 15: Status LEDs on the front (left) and rear (right) of the Netgate 4200 Firewall Appliance

1.5 Safety and Legal

1.5.1 Safety Notices

1. Read, follow, and keep these instructions.
2. Heed all warnings.
3. Only use attachments/accessories specified by the manufacturer.

Warning: Do not use this product in location that can be submerged by water.

Warning: Do not use this product during an electrical storm to avoid electrical shock.

1.5.2 Electrical Safety Information

1. Compliance is required with respect to voltage, frequency, and current requirements indicated on the manufacturer's label. Connection to a different power source than those specified may result in improper operation, damage to the equipment or pose a fire hazard if the limitations are not followed.
2. There are no operator serviceable parts inside this equipment. Service should be provided only by a qualified service technician.
3. This equipment is provided with a detachable power cord which has an integral safety ground wire intended for connection to a grounded safety outlet.

- a) Do not substitute the power cord with one that is not the provided approved type. If a 3 prong plug is provided, never use an adapter plug to connect to a 2-wire outlet as this will defeat the continuity of the grounding wire.
- b) The equipment requires the use of the ground wire as a part of the safety certification, modification or misuse can provide a shock hazard that can result in serious injury or death.
- c) Contact a qualified electrician or the manufacturer if there are questions about the installation prior to connecting the equipment.
- d) Protective grounding/earthing is provided by Listed AC adapter. Building installation shall provide appropriate short-circuit backup protection.
- e) Protective bonding must be installed in accordance with local national wiring rules and regulations.

Warning: To help protect your Netgate appliance from sudden, transient increases and decreases in electrical power, use a surge suppressor, line conditioner, uninterruptible power supply (UPS) or a combination of those devices.

Failure to take such precautions could result in premature failure, and/or damage to your Netgate appliance, which is not covered under the product warranty. Such an event may also present the risk of electric shock, fire, or explosion.

1.5.3 FCC Compliance

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential environment.

1.5.4 Industry Canada

This Class B digital apparatus complies with Canadian ICES-3(B). Cet appareil numérique de la classe B est conforme à la norme NMB-3(B) Canada.

1.5.5 Australia and New Zealand

This is an AMC Compliance level 2 product. This product is suitable for domestic environments.

1.5.6 CE Marking

CE marking on this product represents the product is in compliance with all directives that are applicable to it.

1.5.7 RoHS/WEEE Compliance Statement

English

European Directive 2002/96/EC requires that the equipment bearing this symbol on the product and/or its packaging must not be disposed of with unsorted municipal waste. The symbol indicates that this product should be disposed of separately from regular household waste streams. It is your responsibility to dispose of this and other electric and electronic equipment via designated collection facilities appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. For more detailed information about the disposal of your old equipment, please contact your local authorities, waste disposal service, or the shop where you purchased the product.

Deutsch

Die Europäische Richtlinie 2002/96/EC verlangt, dass technische Ausrüstung, die direkt am Gerät und/oder an der Verpackung mit diesem Symbol versehen ist, nicht zusammen mit unsortiertem Gemeindeabfall entsorgt werden darf. Das Symbol weist darauf hin, dass das Produkt von regulärem Haushaltmüll getrennt entsorgt werden sollte. Es liegt in Ihrer Verantwortung, dieses Gerät und andere elektrische und elektronische Geräte über die dafür zuständigen und von der Regierung oder örtlichen Behörden dazu bestimmten Sammelstellen zu entsorgen. Ordnungsgemäßes Entsorgen und Recyceln trägt dazu bei, potentielle negative Folgen für Umwelt und die menschliche Gesundheit zu vermeiden. Wenn Sie weitere Informationen zur Entsorgung Ihrer Altgeräte benötigen, wenden Sie sich bitte an die örtlichen Behörden oder städtischen Entsorgungsdienste oder an den Händler, bei dem Sie das Produkt erworben haben.

Español

La Directiva 2002/96/CE de la UE exige que los equipos que lleven este símbolo en el propio aparato y/o en su embalaje no deben eliminarse junto con otros residuos urbanos no seleccionados. El símbolo indica que el producto en cuestión debe separarse de los residuos domésticos convencionales con vistas a su eliminación. Es responsabilidad suya desechar este y cualesquiera otros aparatos eléctricos y electrónicos a través de los puntos de recogida que ponen a su disposición el gobierno y las autoridades locales. Al desechar y reciclar correctamente estos aparatos estará contribuyendo a evitar posibles consecuencias negativas para el medio ambiente y la salud de las personas. Si desea obtener información más detallada sobre la eliminación segura de su aparato usado, consulte a las autoridades locales, al servicio de recogida y eliminación de residuos de su zona o pregunte en la tienda donde adquirió el producto.

Français

La directive européenne 2002/96/CE exige que l'équipement sur lequel est apposé ce symbole sur le produit et/ou son emballage ne soit pas jeté avec les autres ordures ménagères. Ce symbole indique que le produit doit être éliminé dans un circuit distinct de celui pour les déchets des ménages. Il est de votre responsabilité de jeter ce matériel ainsi que tout autre matériel électrique ou électronique par les moyens de collecte indiqués par le gouvernement et les pouvoirs publics des collectivités territoriales. L'élimination et le recyclage en bonne et due forme ont pour but de lutter contre l'impact néfaste potentiel de ce type de produits sur l'environnement et la santé publique. Pour plus d'informations sur le mode d'élimination de votre ancien équipement, veuillez prendre contact avec les pouvoirs publics locaux, le service de traitement des déchets, ou l'endroit où vous avez acheté le produit.

Italiano

La direttiva europea 2002/96/EC richiede che le apparecchiature contrassegnate con questo simbolo sul prodotto e/o sull'imballaggio non siano smaltite insieme ai rifiuti urbani non differenziati. Il simbolo indica che questo prodotto non deve essere smaltito insieme ai normali rifiuti domestici. È responsabilità del proprietario smaltire sia questi prodotti sia le altre apparecchiature elettriche ed elettroniche mediante le specifiche strutture di raccolta indicate dal governo o dagli enti pubblici locali. Il corretto smaltimento ed il riciclaggio aiuteranno a prevenire conseguenze potenzialmente negative per l'ambiente e per la salute dell'essere umano. Per ricevere informazioni più dettagliate circa lo smaltimento delle vecchie apparecchiature in Vostro possesso, Vi invitiamo a contattare gli enti pubblici di competenza, il servizio di smaltimento rifiuti o il negozio nel quale avete acquistato il prodotto.

1.5.8 Declaration of Conformity

Česky[Czech]

NETGATE tímto prohlašuje, že tento NETGATE zařízení, je ve shodě se základními požadavky a dalšími požadavkami na měřítku 1999/5/ES.

Dansk [Danish]

Undertegnede NETGATE erklærer herved, at følgende udstyr NETGATE device, overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Nederlands [Dutch]

Hierbij verklaart NETGATE dat het toestel NETGATE device, in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG. Bij deze verklaart NETGATE dat deze NETGATE device, voldoet aan de essentiële eisen en aan de overige relevante bepalingen van Richtlijn 1999/5/EC.

English

Hereby, NETGATE , declares that this NETGATE device, is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Eesti [Estonian]

Käesolevaga kinnitab NETGATE seadme NETGATE device, vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

Suomi [Finnish]

NETGATE vakuuttaa täten että NETGATE device, tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen. Français [French] Par la présente NETGATE déclare que l'appareil Netgate, device est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Deutsch [German]

Hiermit erklärt Netgate, dass sich diese NETGATE device, in Übereinstimmung mit den grundlegenden Anforderungen und den anderen relevanten Vorschriften der Richtlinie 1999/5/EG befindet". (BMW)

Ελληνικά [Greek]

ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ NETGATE ΔΗΛΩΝΕΙ ΟΤΙ NETGATE device, ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙ-ΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1995/5/EK.

Magyar [Hungarian]

Alulírott, NETGATE nyilatkozom, hogy a NETGATE device, megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

Íslenska [Icelandic]

Hér me l sir NETGATE yfir ví a NETGATE device, er í samræmi vi grunnkröfur og a rar kröfur, sem ger ar eru í tilskipun 1999/5/EC.

Italiano [Italian]

Con la presente NETGATE dichiara che questo NETGATE device, è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Latviski [Latvian]

Ar o NETGATE deklar , ka NETGATE device, atbilst Direkt vas 1999/5/EK b tiskaj m pras b m un citiem ar to saist tajiem noteikumiem.

Lietuviškai [Lithuanian]

NETGATE deklaruoja, kad šis NETGATE įrenginys atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Malti [Maltese]

Hawnhekk, Netgate, jiddikjara li dan NETGATE device, jikkonforma mal- ti ijiet essenziali u ma provvedimenti o rajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Norsk [Norwegian]

NETGATE erklærer herved at utstyret NETGATE device, er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

Slovensky [Slovak]

NETGATE tento vyhlasuje, že NETGATE device, je v súlade s základnými požiadavkami a všetkými príslušnými ustanoveniami Smernice 1999/5/ES.

Svenska [Swedish]

Härmed intygar NETGATE att denna NETGATE device, står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Español [Spanish]

Por medio de la presente NETGATE declara que el NETGATE device, cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

Polski [Polish]

Niniejszym, firma NETGATE oznacza, że produkt serii NETGATE device, spełnia zasadnicze wymagania i inne istotne postanowienia Dyrektywy 1999/5/EC.

Português [Portuguese]

NETGATE declara que este NETGATE device, está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Română [Romanian]

Prin prezenta, NETGATE declară că acest dispozitiv NETGATE este în conformitate cu cerințele esențiale și alte prevederi relevante ale Directivei 1999/5/CE.

1.5.9 Disputes

ANY DISPUTE OR CLAIM RELATING IN ANY WAY TO YOUR USE OF ANY PRODUCTS/SERVICES, OR TO ANY PRODUCTS OR SERVICES SOLD OR DISTRIBUTED BY RCL OR ESF WILL BE RESOLVED BY BINDING ARBITRATION IN AUSTIN, TEXAS, RATHER THAN IN COURT. The Federal Arbitration Act and federal arbitration law apply to this agreement.

THERE IS NO JUDGE OR JURY IN ARBITRATION, AND COURT REVIEW OF AN ARBITRATION AWARD IS LIMITED. HOWEVER, AN ARBITRATOR CAN AWARD ON AN INDIVIDUAL BASIS THE SAME DAMAGES AND RELIEF AS A COURT (INCLUDING INJUNCTIVE AND DECLARATORY RELIEF OR STATUTORY DAMAGES), AND MUST FOLLOW THE TERMS OF THESE TERMS AND CONDITIONS OF USE AS A COURT WOULD.

To begin an arbitration proceeding, you must send a letter requesting arbitration and describing your claim to the following:

Rubicon Communications LLC
Attn.: Legal Dept.
4616 West Howard Lane, Suite 900
Austin, Texas 78728
legal@netgate.com

The arbitration will be conducted by the American Arbitration Association (AAA) under its rules. The AAA's rules are available at www.adr.org. Payment of all filing, administration and arbitrator fees will be governed by the AAA's rules.

We each agree that any dispute resolution proceedings will be conducted only on an individual basis and not in a class, consolidated or representative action. We also both agree that you or we may bring suit in court to enjoin infringement or other misuse of intellectual property rights.

1.5.10 Applicable Law

By using any Products/Services, you agree that the Federal Arbitration Act, applicable federal law, and the laws of the state of Texas, without regard to principles of conflict of laws, will govern these terms and conditions of use and any dispute of any sort that might arise between you and RCL and/or ESF. Any claim or cause of action concerning these terms and conditions or use of the RCL and/or ESF website must be brought within one (1) year after the claim or cause of action arises. Exclusive jurisdiction and venue for any dispute or claim arising out of or relating to the parties' relationship, these terms and conditions, or the RCL and/or ESF website, shall be with the arbitrator and/or courts located in Austin, Texas. The judgment of the arbitrator may be enforced by the courts located in Austin, Texas, or any other court having jurisdiction over you.

1.5.11 Site Policies, Modification, and Severability

Please review our other policies, such as our pricing policy, posted on our websites. These policies also govern your use of Products/Services. We reserve the right to make changes to our site, policies, service terms, and these terms and conditions of use at any time.

1.5.12 Miscellaneous

If any provision of these terms and conditions of use, or our terms and conditions of sale, are held to be invalid, void or unenforceable, the invalid, void or unenforceable provision shall be modified to the minimum extent necessary in order to render it valid or enforceable and in keeping with the intent of these terms and conditions. If such modification is not possible, the invalid or unenforceable provision shall be severed, and the remaining terms and conditions shall be enforced as written. Headings are for reference purposes only and in no way define, limit, construe or describe the scope or extent of such section. Our failure to act with respect to a breach by you or others does not waive our right to act with respect to subsequent or similar breaches. These terms and conditions set forth the entire understanding and agreement between us with respect to the subject matter hereof, and supersede any prior oral or written agreement pertaining thereto, except as noted above with respect to any conflict between these terms and conditions and our reseller agreement, if the latter is applicable to you.

1.5.13 Limited Warranty

DISCLAIMER OF WARRANTIES AND LIMITATION OF LIABILITY

THE PRODUCTS/SERVICES AND ALL INFORMATION, CONTENT, MATERIALS, PRODUCTS (INCLUDING SOFTWARE) AND OTHER SERVICES INCLUDED ON OR OTHERWISE MADE AVAILABLE TO YOU THROUGH THE PRODUCTS/SERVICES ARE PROVIDED BY US ON AN “AS IS” AND “AS AVAILABLE” BASIS, UNLESS OTHERWISE SPECIFIED IN WRITING. WE MAKE NO REPRESENTATIONS OR WARRANTIES OF ANY KIND, EXPRESS OR IMPLIED, AS TO THE OPERATION OF THE PRODUCTS/SERVICES, OR THE INFORMATION, CONTENT, MATERIALS, PRODUCTS (INCLUDING SOFTWARE) OR OTHER SERVICES INCLUDED ON OR OTHERWISE MADE AVAILABLE TO YOU THROUGH THE PRODUCTS/SERVICES, UNLESS OTHERWISE SPECIFIED IN WRITING. YOU EXPRESSLY AGREE THAT YOUR USE OF THE PRODUCTS/SERVICES IS AT YOUR SOLE RISK.

TO THE FULL EXTENT PERMISSIBLE BY APPLICABLE LAW, RUBICON COMMUNICATIONS, LLC (RCL) AND ELECTRIC SHEEP FENCING (ESF) DISCLAIM ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. RCL AND ESF DO NOT WARRANT THAT THE PRODUCTS/SERVICES, INFORMATION, CONTENT, MATERIALS, PRODUCTS (INCLUDING SOFTWARE) OR OTHER SERVICES INCLUDED ON OR OTHERWISE MADE AVAILABLE TO YOU THROUGH THE PRODUCTS/SERVICES, RCL’S OR ESF’S SERVERS OR ELECTRONIC COMMUNICATIONS SENT FROM RCL OR ESF ARE FREE OF VIRUSES OR OTHER HARMFUL COMPONENTS. RCL AND ESF WILL NOT BE LIABLE FOR ANY DAMAGES OF ANY KIND ARISING FROM THE USE OF ANY PRODUCTS/SERVICES, OR FROM ANY INFORMATION, CONTENT, MATERIALS, PRODUCTS (INCLUDING SOFTWARE) OR OTHER SERVICES INCLUDED ON OR OTHERWISE MADE AVAILABLE TO YOU THROUGH ANY PRODUCTS/SERVICES, INCLUDING, BUT NOT LIMITED TO DIRECT, INDIRECT, INCIDENTAL, PUNITIVE, AND CONSEQUENTIAL DAMAGES, UNLESS OTHERWISE SPECIFIED IN WRITING.

IN NO EVENT WILL RCL’S OR ESF’S LIABILITY TO YOU EXCEED THE PURCHASE PRICE PAID FOR THE PRODUCT OR SERVICE THAT IS THE BASIS OF THE CLAIM.

CERTAIN STATE LAWS DO NOT ALLOW LIMITATIONS ON IMPLIED WARRANTIES OR THE EXCLUSION OR LIMITATION OF CERTAIN DAMAGES. IF THESE LAWS APPLY TO YOU, SOME OR ALL OF THE ABOVE DISCLAIMERS, EXCLUSIONS, OR LIMITATIONS MAY NOT APPLY TO YOU, AND YOU MIGHT HAVE ADDITIONAL RIGHTS.

HOW-TO GUIDES

2.1 Determine Netgate 4200 Firmware Type

The Netgate® 4200 Desktop Firewall Appliance has two variations which are primarily differentiated by the platform firmware.

Note: Though UEFI platform firmware is not technically a “BIOS” in the traditional sense, it is still commonly referred to as a “BIOS” in practice since end users are familiar with that term.

The two firmware variants are:

- AMI
- Slim Bootloader (SBL)

Note: SBL boots much faster than AMI. Connect to the console before booting the device to ensure the console receives all possible output.

2.1.1 Dashboard Widget Method

Log into the pfSense® Plus GUI and check the **BIOS** section of the **System Information** Dashboard widget. The contents of that widget section contain information which identifies the hardware variant.

Netgate 4200 devices running AMI firmware will appear as follows:

BIOS	Vendor: American Megatrends International, LLC. Version: 8.01 Release Date: Thu Feb 1 2024 Boot Method: UEFI
-------------	---

Fig. 1: System Information Dashboard widget on Netgate 4200 device with AMI firmware

Netgate 4200 devices running SBL will appear as follows:



Fig. 2: System Information Dashboard widget on Netgate 4200 device with SBL

2.1.2 Boot Output Method

When the device boots, the first output from the firmware informs users how to enter the firmware setup, among other information. This output is different on each type of firmware.

Netgate 4200 devices running AMI firmware will appear as follows:

```
Version 2.22.1285. Copyright (C) 2024 AMI
BIOS Date: 02/01/2024 15:18:05 Ver: 2AZRT81
Press <DEL> or <ESC> to enter setup.
```

Netgate 4200 devices running SBL briefly show initialization output followed by a prompt.

SBL initialization appears as follows:

```
Intel Slim Bootloader
SBID: VAL-SL00
ISVN: 001
IVER: 001.000.002.000.00001
BOOT: BP0
MODE: 1
BoardID: 0x09
Memory Init
Silicon Init
MP Init
PCI Enum
ACPI Init
VBT not found 80000003
```

The SBL boot prompt appears as follows:

```
F2 or Down      to enter Setup.
F7              to enter Boot Manager Menu.
ENTER          to boot directly.
```

2.1.3 Firmware Configuration Screen

The firmware setup screen is much different for each firmware type. When the console displays the setup screen, the two types can be differentiated by comparing against the following images:

Netgate 4200 devices running AMI firmware will appear as follows:

Netgate 4200 devices running SBL will appear as follows:




Fig. 3: Firmware Configuration Screen on AMI firmware




Fig. 4: SBL Firmware Configuration Screen

2.1.4 Hardware Sticker Method

Each device has a unique **Serial Number** (SN) printed on a sticker on the underside of the hardware. The serial number value can differentiate between firmware types as follows:

- Serial numbers starting with 2008 or higher values (e.g. 2008xxxxxx) contain SBL firmware.
- Serial numbers starting with lower values, such as 2003 (e.g. 2003xxxxxx) contain AMI firmware.

2.2 Netgate 4200 Wall Mount

The Netgate 4200 has an optional Wall Mount Kit available. This page provides an overview for attaching the system to the wall using this kit.

2.2.1 Kit Contents

The Netgate 4200 Wall Mount Kit contains all components necessary to mount the 4200.



Fig. 5: Netgate 4200 Wall Mount Kit Contents

The kit contains:

- 2x Device wall mount brackets which attach to the Netgate 4200
- 1x Power supply wall mount bracket
- 4x M4x12 socket head cap screws which attach the device wall mount brackets to the Netgate 4200
- 8x Drywall anchors and matching screws

2.2.2 Required Tools

The following tools are required for this procedure:

- 3mm hex key or driver for the M4x12 socket head cap screws
- Phillips screwdriver for the drywall anchors and screws
- Pencil to mark anchor positions on the wall

2.2.3 Wall Mount Orientation

The Netgate 4200 Wall Mount can be attached using an *inboard* orientation, or an *outboard* orientation.

In either orientation, secure the bracket to the Netgate 4200 case with the four included M4x12 socket head cap screws (two per side) using a 3mm hex key or driver. Do not overtighten the screws. The brackets can be mounted to the case before hanging it on the wall.

Inboard Wall Mount Instructions


The inboard wall mount orientation has a narrower profile, with the brackets turning under the device. This method has a more compact and cleaner look, but can be trickier to mount as it requires using the template to mark and place the screws.

Click on the button below to download the Wall Mount Template.

Print the template out at **100% Scale** for it to be accurate.



Fig. 6: The Netgate 4200 *Inboard* Wall Mount Orientation



Note: The 100% Scale setting varies by PDF reader, printer manufacturer, and model.

Follow the pictured instructions on the PDF to complete the wall mount installation.

Outboard Wall Mount Instructions

The outboard wall mount orientation has a wider profile, with the brackets angled away from the device. This method takes more space, but is easier to mount as the brackets can be used to mark and place the screws.

Click on the button below to download the Wall Mount Template.

There are two options to use the template:

1. Print out the first page at **100% Scale** on **8.5" x 17"** paper for it to be accurate.
2. Print pages 2 and 3 at **100% scale** on **8.5" x 11"** paper.

Each page has a dotted line. Cut along the lines and verify the dimensions before using it.

Tip: The mounting brackets themselves can also be used to make the wall markings.



Fig. 7: The Netgate 4200 *Outboard* Wall Mount Orientation



Fig. 8: Using the Wall Mount Bracket to Mark the Screw Locations

2.2.4 Mounting the Power Supply

The mounting bracket for the power supply uses two zip-ties to hold the power supply to the mounting bracket. There is no PDF for the Power Supply Bracket. Use the holes directly to mark the wall for mounting.



2.3 Connecting to the USB Console

This guide shows how to access the serial console which can be used for troubleshooting and diagnostics tasks as well as some basic configuration.

There are times when directly accessing the console is required. Perhaps GUI or SSH access has been locked out, or the password has been lost or forgotten.

2.3.1 USB Serial Console Device

This device uses a **Silicon Labs CP210x USB-to-UART Bridge** which provides access to the console. This device is exposed via the **USB Micro-B (5-pin)** port on the appliance.

Install the Driver

If needed, install an appropriate **Silicon Labs CP210x USB to UART Bridge** driver on the workstation used to connect with the device.

Windows

There are drivers available for Windows [available for download](#).

macOS

There are drivers available for macOS [available for download](#).

For macOS, choose the **CP210x VCP Mac** download.

Linux

There are drivers available for Linux [available for download](#).

FreeBSD

Recent versions of FreeBSD include this driver and will not require manual installation.

Connect a USB Cable

Next, connect to the console port using the cable that has a **USB Micro-B (5-pin)** connector on one end and a **USB Type A** plug on the other end.

Gently push the **USB Micro-B (5-pin)** plug end into the console port on the appliance and connect the **USB Type A** plug into an available USB port on the workstation.

Tip: Be certain to gently push in the **USB Micro-B (5-pin)** connector on the device side completely. With most cables there will be a tangible “click”, “snap”, or similar indication when the cable is fully engaged.

Apply Power to the Device

On some hardware, the USB serial console port may not be detected by the client operating system until the device is plugged into a power source.

If the client OS does not detect the USB serial console port, connect the power cord to the device to allow it to start booting.

If the USB serial console port appears without power applied to the device, then the best practice is to wait until the terminal is open and connected to the serial console before powering on the device. That way the client can view the entire boot output.


Locate the Console Port Device

The appropriate console port device that the workstation assigned as the serial port must be located before attempting to connect to the console.

Note: Even if the serial port was assigned in the BIOS, the workstation OS may remap it to a different COM Port.

Windows

To locate the device name on Windows, open **Device Manager** and expand the section for **Ports (COM & LPT)**. Look for an entry with a title such as **Silicon Labs CP210x USB to UART Bridge**. If there is a label in the name that contains COMX where X is a decimal digit (e.g. COM3), that value is what would be used as the port in the terminal program.



macOS

The device associated with the system console is likely to show up as, or start with, `/dev/cu.usbserial-<id>`.

Run `ls -l /dev/cu.*` from a Terminal prompt to see a list of available USB serial devices and locate the appropriate one for the hardware. If there are multiple devices, the correct device is likely the one with the most recent timestamp or highest ID.

Linux

The device associated with the system console is likely to show up as `/dev/ttyUSB0`. Look for messages about the device attaching in the system log files or by running `dmesg`.

Note: If the device does not appear in `/dev/`, see the note above in the driver section about manually loading the Linux driver and then try again.

FreeBSD

The device associated with the system console is likely to show up as `/dev/cuaU0`. Look for messages about the device attaching in the system log files or by running `dmesg`.

Note: If the serial device is not present, ensure the device has power and then check again.

2.3.2 Launch a Terminal Program

Use a terminal program to connect to the system console port. Some choices of terminal programs:

Windows

For Windows the best practice is to run [PuTTY on Windows](#) or [SecureCRT](#). An example of how to configure PuTTY is below.

Warning: Do not use [HyperTerminal](#).

macOS

For macOS the best practice is to run [GNU screen](#), or `cu`. An example of how to configure [GNU screen](#) is below.

Linux

For Linux the best practices are to run [GNU screen](#), [PuTTY on Linux](#), `minicom`, or `dterm`. Examples of how to configure PuTTY and [GNU screen](#) are below.

FreeBSD

For FreeBSD the best practice is to run [GNU screen](#) or `cu`. An example of how to configure [GNU screen](#) is below.

Client-Specific Examples

PuTTY on Windows

- Open PuTTY and select **Session** under **Category** on the left-hand side.
- Set the **Connection type** to **Serial**
- Set **Serial line** to the [console port determined previously](#)
- Set the **Speed** to **115200** bits per second.
- Click the **Open** button

PuTTY will then display the console.




Fig. 9: An example of using PuTTY on Windows

PuTTY on Linux

- Open PuTTY from a terminal by typing `sudo putty`

Note: The `sudo` command will prompt for the local workstation password of the current account.

- Set the **Connection type** to **Serial**
- Set **Serial line** to `/dev/ttyUSB0`
- Set the **Speed** to **115200** bits per second
- Click the **Open** button

PuTTY will then display the console.



Fig. 10: An example of using PuTTY on Linux

GNU screen

In many cases `screen` may be invoked simply by using the proper command line, where `<console-port>` is the console port that was located above.

```
$ sudo screen <console-port> 115200
```

Note: The `sudo` command will prompt for the local workstation password of the current account.

If portions of the text are unreadable but appear to be properly formatted, the most likely culprit is a character encoding mismatch in the terminal. Adding the `-U` parameter to the `screen` command line arguments forces it to use UTF-8 for character encoding:

```
$ sudo screen -U <console-port> 115200
```

Terminal Settings

The settings to use within the terminal program are:

Speed

115200 baud, the speed of the BIOS

Data bits

8

Parity

None

Stop bits

1

Flow Control

Off or XON/OFF.

Warning: Hardware flow control (RTS/CTS) **must** be disabled.

Terminal Optimization

Beyond the required settings there are additional options in terminal programs which will help input behavior and output rendering to ensure the best experience. These settings vary location and client, and may not be available in all clients or terminals.

These are:

Terminal Type

xterm

This setting may be under Terminal, Terminal Emulation, or similar areas.

Color Support

ANSI colors / 256 Color / ANSI with 256 Colors

This setting may be under Terminal Emulation, Window Colors, Text, Advanced Terminfo, or similar areas.

Character Set / Character Encoding

UTF-8

This setting may be under Terminal Appearance, Window Translation, Advanced International, or similar areas. In GNU screen this is activated by passing the `-U` parameter.

Line Drawing

Look for and enable setting such as “Draw lines graphically”, “Use Unicode graphics characters”, and/or “Use Unicode line drawing code points”.

These settings may be under Terminal Appearance, Window Translation, or similar areas.

Function Keys / Keypad

Xterm R6

In Putty this is under **Terminal > Keyboard** and is labeled **The Function Keys and Keypad**.

Font

For the best experience, use a modern monospaced Unicode font such as DejaVu Sans Mono, Liberation Mono, Monaco, Consolas, Fira Code, or similar.

This setting may be under Terminal Appearance, Window Appearance, Text, or similar areas.

2.3.3 What's Next?

After connecting a terminal client, it may not immediately see any output. This could be because the device has already finished booting, or it may be that the device is waiting for some other input.

If the device does not yet have power applied, plug it in and monitor the terminal output.

If the device is already powered on, try pressing **Space**. If there is still no output, press **Enter**. If the device was booted, it may re-display the console menu or login prompt, or produce other output indicating its status.

From the console, a variety of things are possible, such as changing interface addresses. There is a full explanation of [every console menu option](#) in the pfSense software documentation.

2.3.4 Troubleshooting

Serial Device Missing

With a USB serial console there are a few reasons why the serial port may not be present in the client operating system, including:

No Power

Some models require power before the client can connect to the USB serial console.

USB Cable Not Plugged In

For USB consoles, the USB cable may not be fully engaged on both ends. Gently, but firmly, ensure the cable has a good connection on both sides.

Bad USB Cable

Some USB cables are not suitable for use as data cables. For example, some cables are only capable of delivering power for charging devices and not acting as data cables. Others may be of low quality or have poor or worn connectors.

The ideal cable to use is the one that came with the device. Failing that, ensure the cable is of the correct type and specifications, and try multiple cables.

Wrong Device

In some cases there may be multiple serial devices available. Ensure the one used by the serial client is the correct one. Some devices expose multiple ports, so using the incorrect port may lead to no output or unexpected output.

Hardware Failure

There could be a hardware failure preventing the serial console from working. Contact Netgate TAC for assistance.

No Serial Output

If there is no output at all, check the following items:

USB Cable Not Plugged In

For USB consoles, the USB cable may not be fully engaged on both ends. Gently, but firmly, ensure the cable has a good connection on both sides.

Wrong Device

In some cases there may be multiple serial devices available. Ensure the one used by the serial client is the correct one. Some devices expose multiple ports, so using the incorrect port may lead to no output or unexpected output.

Wrong Terminal Settings

Ensure the terminal program is configured for the correct speed. The default BIOS speed is 115200, and many other modern operating systems use that speed as well.

Some older operating systems or custom configurations may use slower speeds such as 9600 or 38400.

Device OS Serial Console Settings

Ensure the operating system is configured for the proper console (e.g. `ttyS1` in Linux). Consult the various operating installation guides on this site for further information.

PuTTY has issues with line drawing

PuTTY generally handles most cases OK but can have issues with line drawing characters on certain platforms.

These settings seem to work best (tested on Windows):

Window

Columns x Rows

80x24

Window > Appearance

Font

Courier New 10pt or *Consolas 10pt*

Window > Translation

Remote Character Set

Use font encoding or *UTF-8*

Handling of line drawing characters

Use font in both ANSI and OEM modes or *Use Unicode line drawing code points*

Window > Colours

Indicate bolded text by changing

The colour

Garbled Serial Output

If the serial output appears to be garbled, missing characters, binary, or random characters check the following items:

Flow Control

In some cases flow control can interfere with serial communication, causing dropped characters or other issues. Disabling flow control in the client can potentially correct this problem.

On PuTTY and other GUI clients there is typically a per-session option to disable flow control. In PuTTY, the **Flow Control** option is in the settings tree under **Connection**, then **Serial**.

To disable flow control in GNU Screen, add the `-ixon` and/or `-ixoff` parameters after the serial speed as in the following example:

```
$ sudo screen <console port> 115200,-ixon
```

Terminal Speed

Ensure the terminal program is configured for the correct speed. (See [No Serial Output](#))

Character Encoding

Ensure the terminal program is configured for the proper character encoding, such as **UTF-8** or **Latin-1**, depending on the operating system. (See [GNU Screen](#))

Serial Output Stops After the BIOS

If serial output is shown for the BIOS but stops afterward, check the following items:

Terminal Speed

Ensure the terminal program is configured for the correct speed for the installed operating system. (See [No Serial Output](#))

Device OS Serial Console Settings

Ensure the installed operating system is configured to activate the serial console and that it is configured for the proper console (e.g. `ttyS1` in Linux). Consult the various operating installation guides on this site for further information.

Bootable Media

If booting from a USB flash drive, ensure that the drive was written correctly and contains a bootable operating system image.

2.4 Connecting to the RJ45 Console Port

There are times when directly accessing the console is required. Perhaps GUI or SSH access has been locked out, or the password has been lost or forgotten.

A separate adapter is required to make a connection between a computer and the firewall using the RJ45 serial port. This can be a direct **RJ45-to-USB serial** adapter or a standard **USB-to-serial** adapter and an **RJ45-to-DB9** adapter or cable. It is also possible to utilize client hardware serial ports and compatible cables, but these ports are rare on modern hardware.

These are standard components, inexpensive and readily available from most retail outlets that sell computer cables.

Installing drivers and locating the port will vary depending on the third party device, consult its documentation for details.

2.4.1 Launch a Terminal Program

Use a terminal program to connect to the system console port. Some choices of terminal programs:

Windows

For Windows the best practice is to run [PuTTY on Windows](#) or [SecureCRT](#). An example of how to configure PuTTY is below.

Warning: Do not use [HyperTerminal](#).

macOS

For macOS the best practice is to run [GNU screen](#), or [cu](#). An example of how to configure [GNU screen](#) is below.

Linux

For Linux the best practices are to run [GNU screen](#), [PuTTY on Linux](#), [minicom](#), or [dterm](#). Examples of how to configure PuTTY and [GNU screen](#) are below.

FreeBSD

For FreeBSD the best practice is to run [GNU screen](#) or [cu](#). An example of how to configure [GNU screen](#) is below.

Client-Specific Examples

PuTTY on Windows

- Open PuTTY and select **Session** under **Category** on the left-hand side.
- Set the **Connection type** to **Serial**
- Set **Serial line** to the *console port determined previously*
- Set the **Speed** to **115200** bits per second.
- Click the **Open** button

PuTTY will then display the console.

PuTTY on Linux

- Open PuTTY from a terminal by typing `sudo putty`

Note: The `sudo` command will prompt for the local workstation password of the current account.

- Set the **Connection type** to **Serial**
- Set **Serial line** to `/dev/ttyUSB0`
- Set the **Speed** to **115200** bits per second
- Click the **Open** button

PuTTY will then display the console.




Fig. 11: An example of using PuTTY on Windows



Fig. 12: An example of using PuTTY on Linux

GNU screen

In many cases **screen** may be invoked simply by using the proper command line, where <console-port> is the console port that was located above.

```
$ sudo screen <console-port> 115200
```

Note: The **sudo** command will prompt for the local workstation password of the current account.

If portions of the text are unreadable but appear to be properly formatted, the most likely culprit is a character encoding mismatch in the terminal. Adding the **-U** parameter to the **screen** command line arguments forces it to use UTF-8 for character encoding:

```
$ sudo screen -U <console-port> 115200
```

Terminal Settings

The settings to use within the terminal program are:

Speed

115200 baud, the speed of the BIOS

Data bits

8

Parity

None

Stop bits

1

Flow Control

Off or XON/OFF.

Warning: Hardware flow control (RTS/CTS) **must** be disabled.

Terminal Optimization

Beyond the required settings there are additional options in terminal programs which will help input behavior and output rendering to ensure the best experience. These settings vary location and client, and may not be available in all clients or terminals.

These are:

Terminal Type

xterm

This setting may be under Terminal, Terminal Emulation, or similar areas.

Color Support

ANSI colors / 256 Color / ANSI with 256 Colors

This setting may be under Terminal Emulation, Window Colors, Text, Advanced Terminfo, or similar areas.

Character Set / Character Encoding

UTF-8

This setting may be under Terminal Appearance, Window Translation, Advanced International, or similar areas. In GNU screen this is activated by passing the -U parameter.

Line Drawing

Look for and enable setting such as “Draw lines graphically”, “Use Unicode graphics characters”, and/or “Use Unicode line drawing code points”.

These settings may be under Terminal Appearance, Window Translation, or similar areas.

Function Keys / Keypad

Xterm R6

In Putty this is under **Terminal > Keyboard** and is labeled **The Function Keys and Keypad**.

Font

For the best experience, use a modern monospaced Unicode font such as DejaVu Sans Mono, Liberation Mono, Monaco, Consolas, Fira Code, or similar.

This setting may be under Terminal Appearance, Window Appearance, Text, or similar areas.

2.4.2 What's Next?

After connecting a terminal client, it may not immediately see any output. This could be because the device has already finished booting, or it may be that the device is waiting for some other input.

If the device does not yet have power applied, plug it in and monitor the terminal output.

If the device is already powered on, try pressing **Space**. If there is still no output, press **Enter**. If the device was booted, it may re-display the console menu or login prompt, or produce other output indicating its status.

From the console, a variety of things are possible, such as changing interface addresses. There is a full explanation of every console menu option in the pfSense software documentation.

2.4.3 Troubleshooting

Serial Device Missing

With a USB serial console there are a few reasons why the serial port may not be present in the client operating system, including:

No Power

Some models require power before the client can connect to the USB serial console.

USB Cable Not Plugged In

For USB consoles, the USB cable may not be fully engaged on both ends. Gently, but firmly, ensure the cable has a good connection on both sides.

Bad USB Cable

Some USB cables are not suitable for use as data cables. For example, some cables are only capable of delivering power for charging devices and not acting as data cables. Others may be of low quality or have poor or worn connectors.

The ideal cable to use is the one that came with the device. Failing that, ensure the cable is of the correct type and specifications, and try multiple cables.

Wrong Device

In some cases there may be multiple serial devices available. Ensure the one used by the serial client is the correct one. Some devices expose multiple ports, so using the incorrect port may lead to no output or unexpected output.

Hardware Failure

There could be a hardware failure preventing the serial console from working. Contact Netgate TAC for assistance.

No Serial Output

If there is no output at all, check the following items:

USB Cable Not Plugged In

For USB consoles, the USB cable may not be fully engaged on both ends. Gently, but firmly, ensure the cable has a good connection on both sides.

Wrong Device

In some cases there may be multiple serial devices available. Ensure the one used by the serial client is the correct one. Some devices expose multiple ports, so using the incorrect port may lead to no output or unexpected output.

Wrong Terminal Settings

Ensure the terminal program is configured for the correct speed. The default BIOS speed is 115200, and many other modern operating systems use that speed as well.

Some older operating systems or custom configurations may use slower speeds such as 9600 or 38400.

Device OS Serial Console Settings

Ensure the operating system is configured for the proper console (e.g. `ttyS1` in Linux). Consult the various operating installation guides on this site for further information.

PuTTY has issues with line drawing

PuTTY generally handles most cases OK but can have issues with line drawing characters on certain platforms.

These settings seem to work best (tested on Windows):

Window

Columns x Rows

80x24

Window > Appearance

Font

Courier New 10pt or *Consolas 10pt*

Window > Translation

Remote Character Set

Use font encoding or *UTF-8*

Handling of line drawing characters

Use font in both ANSI and OEM modes or *Use Unicode line drawing code points*

Window > Colours

Indicate bolded text by changing

The colour

Garbled Serial Output

If the serial output appears to be garbled, missing characters, binary, or random characters check the following items:

Flow Control

In some cases flow control can interfere with serial communication, causing dropped characters or other issues. Disabling flow control in the client can potentially correct this problem.

On PuTTY and other GUI clients there is typically a per-session option to disable flow control. In PuTTY, the **Flow Control** option is in the settings tree under **Connection**, then **Serial**.

To disable flow control in GNU Screen, add the `-ixon` and/or `-ixoff` parameters after the serial speed as in the following example:

```
$ sudo screen <console port> 115200,-ixon
```

Terminal Speed

Ensure the terminal program is configured for the correct speed. (See [No Serial Output](#))

Character Encoding

Ensure the terminal program is configured for the proper character encoding, such as **UTF-8** or **Latin-1**, depending on the operating system. (See [GNU Screen](#))

Serial Output Stops After the BIOS

If serial output is shown for the BIOS but stops afterward, check the following items:

Terminal Speed

Ensure the terminal program is configured for the correct speed for the installed operating system. (See [No Serial Output](#))

Device OS Serial Console Settings

Ensure the installed operating system is configured to activate the serial console and that it is configured for the proper console (e.g. `ttyS1` in Linux). Consult the various operating installation guides on this site for further information.

Bootable Media

If booting from a USB flash drive, ensure that the drive was written correctly and contains a bootable operating system image.

2.5 Reinstalling pfSense Plus Software

This guide uses the [Netgate Installer](#) to install pfSense® Plus software on a **Netgate 4200** device.

Note: pfSense® Plus is preinstalled on Netgate appliances. It is optimally tuned for Netgate hardware and contains features that cannot be found elsewhere, such as ZFS Boot Environments, OpenVPN DCO, Built-in IPFIX Export, and the [AWS VPC Wizard](#).

2.5.1 Download Installation Media

The Netgate Installer can be downloaded from the [Netgate Store](#) using a [Netgate Store Account](#).

See also:

For a more detailed walkthrough of the download process, see [Download Installation Media](#) in the pfSense Software Documentation.

The image to download for this device is:

`netgate-installer-amd64.img.gz`

2.5.2 Prepare Installation Media

Next, write the installation image to a USB memstick.

See also:

Locating the image and writing it to a USB memstick is covered in detail under [Writing Flash Drives](#).

2.5.3 Connect to the Console

The installation process is interactive and utilizes the console. Follow the directions under [Connect to the console](#) to configure and use the console.

2.5.4 Boot the Installation Media

Before starting, *determine the platform firmware type* (AMI or SBL).

The procedure to boot once from alternate media differs based on the firmware type. Follow the section which matches the firmware type on the device.

2.5.5 AMI

1. Insert the memstick into the USB port on the right side and boot the device.
2. Wait for the boot prompt to appear.
3. Press **Esc** to enter the firmware configuration.
4. Use the left/right arrow keys to select the **Save & Exit** header.




Fig. 13: AMI firmware Boot Override Selection

5. Use the up/down arrow keys to move into the **Boot Override** section.
6. Select the entry for the USB memstick.

The entry is likely at or near the **bottom** of the list. The name of the entry varies by brand/make/model of the USB memstick.

See also:

[Changing the Boot Order in AMI Firmware](#)

2.5.6 SBL

1. Insert the memstick into the USB port on the right side and boot the device.
2. Wait for the boot prompt to appear.
3. Press F7 to enter the boot manager menu.




Fig. 14: SBL Boot Manager Menu

4. Use the up/down arrow keys to highlight a device in the boot manager menu.
5. Press **Enter** to select the entry for the USB memstick.

The entry is likely at or near the **top** of the list. The name of the entry varies by brand/make/model of the USB memstick.

See also:

[Changing the Boot Order in SBL](#)

2.5.7 Determine Target Drive

During the installation process the installer will prompt to select a target drive. The installer will then write pfSense® Plus to the chosen drive.

- On devices with only MMC storage, the only choice is **da0**.
- On devices with multiple drives, such as MAX variants, take care to choose the correct intended target. If the device contains NVMe storage (**nda0**), that is the optimal choice.
- Other USB storage devices appear as **daX** where X is a device number, such as **da2**. The device number may shift depending on the order in which the OS probes USB devices or the order in which they are inserted while the OS is running.

Note: The installation media is also a USB drive, but the installer does not offer its own disk as a target drive.

2.5.8 Install pfSense Plus Software

The installer will automatically launch and present several options. On Netgate appliances, choosing **Enter** for the default options will complete the installation process in most cases.

Tip: There are options on the Welcome screen of the installer which can recover configuration data from a previous installation or from a USB drive.

See also:

For a complete walkthrough of the installation process, see [Installation Walkthrough](#).

When the installation is complete, remove the USB drive from the USB port.

Important: If the USB drive remains attached, the device may boot into the installer again.

See also:

For information on restoring from a previously saved configuration, go to [Backup and Restore](#).

Caution: If this device contains multiple disks, such as when adding an SSD to an existing system which previously used MMC, additional steps may be necessary to ensure the device boots from and uses the correct disk. Furthermore, having separate installations of the software on different disks is a known source of problems. For example, the kernel could boot from one disk while the root filesystem is loaded from another, or they could contain conflicting ZFS pools.

In some cases it is possible to adjust the BIOS boot order to prefer the new disk, but the best practice is to wipe the old disk to remove any chance of the previous installation causing boot issues or conflicts.

For information on how to wipe the old disk, see [Multiple Disk Boot Issues](#).

2.6 Configuring an OPT interface as an additional WAN

This guide configures an OPT port as an additional WAN type interface. These interfaces connect to upstream networks providing connectivity to the Internet or other remote destinations.

See also:

[Multi-WAN documentation](#)

Configuring an additional WAN

- [Requirements](#)
- [Assign the Interface](#)
- [Interface Configuration](#)
- [Outbound NAT](#)
 - [Automatic or Hybrid Outbound NAT](#)
 - [Manual Outbound NAT](#)

- *Firewall Rules*
- *Gateway Groups*
- *DNS*
- *Setup Policy Routing*
- *Dynamic DNS*
- *VPN Considerations*
- *Testing*

2.6.1 Requirements

- This guide assumes the underlying interface is already present (e.g. physical port, VLAN, etc.).
- The WAN configuration type and settings must be known before starting. For example, this might be an IP address, subnet mask, and gateway value for static addresses or credentials for PPPoE.

2.6.2 Assign the Interface

- Navigate to **Interfaces > Assignments**

Look at list of current assignments. If the interface in question is already assigned, there is nothing to do. Skip ahead to the interface configuration.

- Pick an available interface in **Available network ports**

If there are no available interfaces, then one may need to be created first (e.g. VLANs).

- Click  **Add**

The firewall will assign the next available OPT interface number corresponding to the internal interface designation. For example, if there are no current OPT interfaces, the new interface will be **OPT1**. The next will be **OPT2**, and so on.

Note: As this guide does not know what that number will be on a given configuration, it will refer to the interface generically as **OPTx** and the customized name **WAN2**.

The newly assigned interface will have its own entry under the **Interfaces** menu and elsewhere in the GUI.

2.6.3 Interface Configuration

The new interface must be enabled and configured.

- Navigate to **Interfaces > OPTx**
- Check **Enable interface**
- Set custom name in the **Description**, e.g. **WAN2**
- Set IP address and CIDR for static, or DHCP/PPPoE/etc.

See also:[IPv4 Configuration Types](#)

- Create a Gateway if this is a static IP address WAN:

- Click  **Add a New Gateway**
- Configure the gateway as follows:

Default

Check if this new WAN should be the default gateway.

Gateway Name

Name it the same as the interface (e.g. WAN2), or a variation thereof.

Gateway IPv4

The IPv4 address of the gateway inside the same subnet.

Description

Optional text describing the purpose of the gateway.

- Click  **Add**
- Ensure the new gateway is selected as the **IPv4 Upstream Gateway**

- Check **Block private networks**

This will block private network traffic on the interface, though if the firewall rules for this WAN are not permissive, this may be unnecessary.

- Check **Block bogon networks**

This will traffic from bogus or unassigned networks on the interface, though if the firewall rules for this WAN are not permissive, this may be unnecessary.

- Click **Save**

- Click **Apply Changes**

The presence of a selected gateway in the interface configuration causes the firewall to treat the interface as a *WAN type* interface. This is manual for static configurations, as above, but is automatic for dynamic WANs (e.g. DHCP, PPPoE).

The firewall applies outbound NAT to traffic exiting WAN type interfaces but does not use WAN type interface networks as a source for outbound NAT on other interfaces. Firewall rules on WAN type interfaces get `reply-to` added to ensure traffic entering a WAN exits the same WAN, and traffic exiting the interface is nudged toward its gateway. The DNS Resolver will not accept queries from clients on WAN type interfaces without manual ACL entries.

See also:[Interface Configuration](#)

2.6.4 Outbound NAT

For clients on local interfaces to reach the Internet from private addresses to destinations through this WAN, the firewall must apply Outbound NAT on traffic leaving this new WAN.

- Navigate to **Firewall > NAT, Outbound** tab
- Check the current outbound NAT mode and follow the section below which matches the mode.

Automatic or Hybrid Outbound NAT

If the mode is set to **Automatic** or **Hybrid**, then this may not need further configuration.

Ensure there are rules for the new WAN listed as an **Interface** in the **Automatic Rules** at the bottom of the page. If so, skip ahead to the next section to configure Firewall Rules.

Manual Outbound NAT

If the mode is set to **Manual**, create a new rule or set of rules to cover the new WAN.

If there are existing rules in the **Mappings** table, they can be copied and adjusted to use the new WAN. Otherwise, create them manually:

- Click  **Add** to add a new rule at the top of the list.
- Configure the rule as follows:

Interface

Choose the new WAN interface (e.g. **WAN2**)

Address Family

IPv4

Protocol

Any

Source

Either choose *LAN Subnets*, which will automatically reference any networks on the LAN interface, or choose *Network or Alias* and manually fill in the LAN subnet, e.g. **192.168.1.0/24**.

If there are multiple local networks, create rules for each or use other methods such as aliases or CIDR summarization to cover them all.

Destination

Any

Translation Address

WAN2 Address (or the custom name of the new WAN interface)

Description

Text describing the rule, e.g. **LAN outbound on WAN2**

- Click **Save**
- Click **Apply Changes**

Repeat as needed for additional local networks.

2.6.5 Firewall Rules

By default, there are no rules on the new interface, so the firewall will block all traffic. This is ideal for a WAN, so is safe to leave as-is. Adding services on the new WAN, such as VPNs, may require rules, but those should be handled on a case-by-case basis.

Warning: Do not add any blanket “allow all” style rules on any WAN.

2.6.6 Gateway Groups

Gateway Groups do not control traffic directly, but can be used in other places, such as firewall rules and service bindings, to influence how those areas use gateways.

For most scenarios it helps to create three gateway groups to start with: PreferWAN, PreferWAN2, and LoadBalance:

- Navigate to **System > Routing, Gateway Groups** tab



- Click **Add** to create a new gateway group
- Configure the group as follows:

Group Name

PreferWAN

Gateway Priority

Gateway for WAN on **Tier 1**, Gateway for WAN2 on **Tier 2**

Description

Prefer WAN, fail to WAN2

- Click **Save**



- Click **Add** to create another gateway group
- Configure the group as follows:

Group Name

PreferWAN2

Gateway Priority

Gateway for WAN on **Tier 2**, Gateway for WAN2 on **Tier 1**

Description

Prefer WAN2, fail to WAN

- Click **Save**



- Click **Add** to create another gateway group
- Configure the group as follows:

Group Name

LoadBalance

Gateway Priority

Gateways for WAN and WAN2 both on **Tier 1**

Description

Load Balance Connections on WAN and WAN2

Note: Rules using this group enable connection-based load balancing, not per-packet load balancing.

Rules using this group will also have failover style behavior as WANs which are down are removed from load balancing.

- Click **Save**
- Click **Apply Changes**

Now set the default gateway to a failover group:

- Navigate to **System > Routing, Gateways** tab
- Set **Default gateway IPv4** to *PREFERWAN*
- Click **Save**
- Click **Apply Changes**

Note: This is important for failover from the firewall itself so it always has outbound access. While this also enables basic failover for client traffic, it's better to use policy routing rules to control client traffic behavior.

2.6.7 DNS

DNS is critical for Internet access, and it is important to ensure the firewall can always resolve hostnames using DNS even when running on a secondary WAN.

The needs here depend upon the configuration of the DNS Resolver or Forwarder.

If the DNS Resolver is in its default resolver mode, then default gateway switching will be sufficient to handle failover in most cases, though it may not be as reliable as using forwarding mode.

If the DNS Resolver is in forwarding mode or the firewall is using the DNS Forwarder instead, then maintaining functional DNS requires manually configuring gateways for forwarding DNS servers.

- Navigate to **System > General Setup**
- Add at least one DNS server for each WAN in the **DNS Server Settings** section, ideally two or more. Click



Add DNS Server to create additional rows.

Each entry should be configured as follows:

Address

The IP address of a DNS server.

Each server address **must be unique**, the same server **cannot** be listed more than once.

DNS Hostname

Leave this field blank unless the server will be contacted using DNS over TLS through the DNS Resolver. In this case, enter the FQDN of the DNS server, so its name can be validated against its TLS certificate.

Gateway

Select a gateway for each DNS server, corresponding to the WAN through which the firewall can reach the DNS server.

For public DNS servers such as CloudFlare or Google, either WAN is OK, but if either WAN uses DNS servers from a specific ISP, ensure those exit the appropriate WAN.

Note: If the gateway drop-down does not appear next to each DNS server, then the firewall does not have more than one gateway configured for any address family. Double-check the gateway settings for all WAN interfaces.

- Uncheck **DNS Server Override**

This will tell the firewall to use the DNS servers entered on this page and to ignore servers provided by dynamic WANs such as DHCP or PPPoE. Occasionally these providers may push conflicting DNS server information, so the best practice is to assign the DNS servers manually.

- Click **Save**

Note: If the DNS Resolver has specific outgoing interfaces selected in its configuration, select the new WAN there well as well.

2.6.8 Setup Policy Routing

Policy routing involves setting a gateway on firewall rules which direct matching traffic out specific WANs or failover groups.

In simple cases (one LAN, no VPNs) the only requirement to configure policy routing is to add a gateway to existing rules.

- Navigate to **Firewall > Rules, LAN tab**
- Edit the default pass rule for the LAN
- Click **Display Advanced**
- Set the **Gateway** to one of the gateway groups based on the desired LAN client behavior.
For example, pick *PreferWAN*, so clients use WAN and then if WAN fails, they use WAN2.
- Click **Save**
- Click **Apply Changes**

If there are other local networks or VPNs which clients on LAN must reach, add rules **above** the default pass rules to pass local traffic without a gateway set:

- Navigate to **Firewall > Rules, LAN tab**

- Click  to add a new rule at the **top** of the list
- Configure the rule as follows:

Action

Pass

Interface

LAN

Protocol

Any

Source*LAN subnets***Destination**

The other local subnet, VPN network, or an alias of such networks.

Description

Pass to local and VPN networks

Do not set a gateway on this rule.

- Click **Save**
- Click **Apply Changes**

2.6.9 Dynamic DNS

Dynamic DNS provides several benefits for multiple WANs, particularly with VPNs. If the firewall does not already have one or more Dynamic DNS hostnames configured, consider signing up with a provider and creating one or more.

It is a good practice to have a separate DNS entry for each WAN and a shared entry for failover, or one per failover group. If that is not viable, at least have one for the most common needs.

The particulars of configuring Dynamic DNS entries vary by provider and are beyond the scope of this document.

2.6.10 VPN Considerations

IPsec can use a gateway group as an interface, but needs a dynamic DNS hostname as companion. The remote peer would need to use the Dynamic DNS hostname as the peer address of this firewall instead of an IP address. Because this relies on DNS, failover can be slow.

WireGuard does not bind to an interface, but can work with Multi-WAN. It will respond from WAN2 if client contacts WAN2, but when initiating it will always use the current default gateway. Static routes can nudge traffic for a specific peer out a specific WAN.

OpenVPN can use a gateway group as an interface for clients or servers. Client behavior is OK and should match default failover behavior configured on the group. For servers, it is better to bind the server to localhost and use port forwards from each WAN to localhost. Remote clients can then have multiple remote entries and contact each WAN as needed at any time.

2.6.11 Testing

Methods for testing depend on the type of WANs and gateway groups in use.

- For most WANs, a better test is to unplug the **upstream** connection from the ISP Customer Premise Equipment (CPE). This more accurately simulates a typical type of upstream connectivity failure. Do not power off the CPE or unplug the connection between the firewall and the CPE. While this may work, it's a much less common scenario and can behave differently.
- For testing load balancing, use cURL or multiple browsers/sessions when checking the IP address multiple times. Refreshing the same browser window will reuse a connection to the server and is not helpful for testing connection-based load balancing.

2.7 Configuring an OPT interface as an additional LAN

This guide configures an OPT port as an additional LAN type interface. These local interfaces can perform a variety of tasks, such as being a guest network, DMZ, IOT isolation, wireless segment, lab network, and more.

Configuring an additional LAN

- *Requirements*
- *Assign the Interface*
- *Interface Configuration*
- *DHCP Server*
- *Outbound NAT*
 - *Automatic or Hybrid Outbound NAT*
 - *Manual Outbound NAT*
- *Firewall Rules*
 - *Open*
 - *Isolated*
- *Other Services*

2.7.1 Requirements

- This guide assumes the underlying interface is already present (e.g. physical port, VLAN, etc.).
- Choose a new local subnet to use for the additional LAN type interface. This example uses 192.168.2.0/24.

2.7.2 Assign the Interface

The first step is to assign an OPT interface.

- Navigate to **Interfaces > Assignments**

Look at list of current assignments. If the interface in question is already assigned, there is nothing to do. Skip ahead to the interface configuration.

- Pick an available interface in **Available network ports**

If there are no available interfaces, then one may need to be created first (e.g. VLANs).

- Click  **Add**

The firewall will assign the next available OPT interface number corresponding to the internal interface designation. For example, if there are no current OPT interfaces, the new interface will be **OPT1**. The next will be **OPT2**, and so on.

Note: As this guide does not know what that number will be on a given configuration, it will refer to the interface generically as **OPTx**.

The newly assigned interface will have its own entry under the **Interfaces** menu and elsewhere in the GUI.

2.7.3 Interface Configuration

The new interface must be enabled and configured.

- Navigate to **Interfaces > OPTx**
- Check **Enable interface**
- Set custom name in the **Description**, e.g. GUESTS, DMZ, etc.
- Set the **IPv4 Address** and CIDR mask for the new LAN

For this example, 192.168.2.1/24.

- **Do not** add or choose an **IPv4 Upstream gateway**

- Uncheck **Block private networks**

This interface is a private network, this option would prevent it from functioning.

- Uncheck **Block bogon networks**

The rules on this interface should only allow traffic from the subnet on the interface, making this option unnecessary.

- Click **Save**

- Click **Apply Changes**

The lack of a selected gateway in the interface configuration causes the firewall to treat the interface as a *LAN type* interface.

The firewall uses LAN type interfaces as sources of outbound NAT traffic but does not apply outbound NAT on traffic exiting a LAN. The firewall does not add any extra properties on firewall rules to influence traffic behavior. The DNS Resolver will accept queries from clients on LAN type interfaces.

See also:

[Interface Configuration](#)

2.7.4 DHCP Server

Next, configure DHCP service for this local interface. This is a convenient and easy way assign addresses for clients on the interface, but is optional if clients will be statically addressed instead.

This configuration varies slightly depending on the DHCP server and version.

See also:

[DHCPv4 Configuration](#)

- Navigate to **Services > DHCP Server, OPTx tab** (or the custom name)
- Check **Enable**
- Configure the **Address Pool Range**, e.g. from 192.168.2.100 to 192.168.2.199
 - This sets the lower (**From**) and upper (**To**) bound of automatic addresses assigned to clients.
- The rest of the settings can be left at defaults
- Click **Save**

2.7.5 Outbound NAT

For clients on this interface to reach the Internet from private addresses, the firewall must apply Outbound NAT for the new subnet.

- Navigate to **Firewall > NAT, Outbound** tab
- Check the current outbound NAT mode and follow the section below which matches the mode.

Automatic or Hybrid Outbound NAT

If the mode is set to **Automatic** or **Hybrid**, then this likely does not need further configuration.

Ensure the new LAN subnet is listed as a **Source** in the **Automatic Rules** at the bottom of the page. If so, skip ahead to the next section to configure Firewall Rules.

Manual Outbound NAT

If the mode is set to **Manual**, create a new rule or set of rules to cover the new subnet.

- Click  **Add** to add a new rule at the top of the list
- Configure the rule as follows:

Interface

Choose the WAN interface. If there is more than one WAN interface, add separate rules for each WAN interface.

Address Family

IPv4

Protocol

Any

Source

Either choose *OPTx Subnets*, which will automatically reference the new interface, or choose *Network or Alias* and manually fill in the new subnet, e.g. *192.168.2.0/24*.

Destination

Any

Translation Address

WAN Address (or the customized name matching the WAN/egress interface)

Description

Text describing the rule, e.g. *Guest LAN outbound on WAN*

- Click **Save**
- Click **Apply Changes**

Alternately, clone existing NAT rules and adjust as needed to match the new LAN.

2.7.6 Firewall Rules

By default, there are no firewall rules on the new interface, so the firewall will block all traffic. This is not ideal for a LAN as generally speaking, the clients on this LAN will need to contact hosts through the firewall.

Rules for this interface can be found under **Firewall > Rules**, on the **OPTx** tab (or the custom name, e.g. **GUESTS**).

There are two common scenarios administrators typically choose for local interfaces: Open and Isolated

Open

On an open LAN, hosts in that LAN are free to contact any other host through the firewall. This might be a host on the Internet, across a VPN, or on another local LAN.

In this case a simple “allow all” style rule for the interface will suffice.

- Navigate to **Firewall > Rules**, on the **OPTx** tab (or the custom name)

- Click  to add a new rule at the top of the list
- Configure the rule as follows:

Action

Pass

Interface

OPTx (or the custom name) should already be set by default

Protocol

Any

Source

OPTx subnets (or the custom name)

Destination

Any

Description

Text describing the rule, e.g. `Default allow all from OPTx`

- Click **Save**

- Click **Apply Changes**

Isolated

In an isolated local network, hosts on the network cannot contact hosts on other networks unless explicitly allowed in the rules. Hosts can still contact the Internet as needed in this example, but that can also be restricted with additional rules.

This scenario is common for locked down networks such as for IOT devices, a DMZ with public services, untrusted Guest/BYOD networks, and other similar scenarios.

Warning: A full set of reject rules as described in this example is the best practice. Do not rely on shortcuts such as using policy routing to isolate clients.

Create a Private Networks Alias

Create an alias using all RFC 1918 networks (listed in the example below) or at least an alias containing the local/private networks on this firewall, such as VPNs. Using all RFC 1918 networks is a safer practice.

- Navigate to **Firewall > Aliases**

- Click  **Add**
- Configure the alias as follows:

Name
PrivateNets

Description
Private Networks

Type
Network(s)

- Add entries for:
 - 192.168.0.0/16
 - 172.16.0.0/12
 - 10.0.0.0/8
- Click **Save**

Add Firewall Rules

With the alias in place, the next task is to create firewall rules for the interface.

- Navigate to **Firewall > Rules**, on the **OPTx** tab (or the custom name)

Allow DNS

Add rule to allow DNS requests from local clients to the firewall itself or other DNS servers.

- Click  **Add** to add a new rule at the bottom of the list.
- Configure the rule as follows:

Action
Pass

Interface
OPTx (or the custom name)

Protocol
TCP/UDP

Source
OPTx subnets (or the custom name)

Destination

This Firewall (self)

If clients are configured to query DNS servers other than this firewall, create rules using those as the destination instead.

Destination Port Range

Select the *DNS (53)* entry or choose *Other* and manually enter 53

To allow DNS over TLS, create a separate rule using the *DNS over TLS* entry or manually enter port 853.

Description

Text describing the rule, e.g. *Allow clients to resolve DNS through the firewall*

- Click **Save**

Allow ICMP to the Firewall

Add a rule to allow ICMP traffic from local devices to the firewall.



- Click **Add** to add a new rule at the bottom of the list.
- Configure the rule as follows:

Action

Pass

Interface

OPTx (or the custom name)

Protocol

ICMP

ICMP Subtype

Any

Tip: While ICMP is useful, some network administrators prefer to limit the allowed ICMP types to *Echo Request* only. This allows devices to use ICMP ping for diagnostic purposes, but no other types of ICMP traffic.

Source

OPTx subnets (or the custom name)

Destination

This Firewall (self)

Description

Allow client ICMP to the firewall

- Click **Save**

Reject Other Firewall-bound Traffic

Add rule to reject any other traffic to the firewall to ensure users on this interface cannot connect to management services such as the GUI, SSH, and so on.



- Click **Add** to add a new rule at the bottom of the list.
- Configure the rule as follows:

Action*Reject***Interface***OPTx (or the custom name)***Protocol***Any***Source***Any***Destination***This Firewall (self)***Description***Reject all other traffic to the firewall*

- Click **Save**

Reject Private Traffic

Add rule to reject traffic from this network to all other private networks.



- Click **Add** to add a new rule at the bottom of the list.
- Configure the rule as follows:

Action*Reject***Interface***OPTx (or the custom name)***Protocol***Any***Source***Any***Destination***Address or Alias, PrivateNets (the alias created earlier)***Description***Reject all other traffic to private networks*

- Click **Save**

Allow Other Traffic

Add rule to allow traffic from this interface network to any other destination, which enables clients on this interface to reach the Internet and/or other remote public networks.

- Click  **Add** to add a new rule at the bottom of the list.
- Configure the rule as follows:

Action
Pass

Interface
OPTx (or the custom name)

Protocol
Any

Source
OPTx subnets (or the custom name)

Destination
Any

Description
Default allow all from OPTx

- Click **Save**

Apply Changes

With the rules all in place, click **Apply Changes** to finish and activate the new rules.

The rules should look similar to the following figure:

Rules (Drag to Change Order)										
Actions	Description	Schedule	Queue	Gateway	Port	Destination	Source	Protocol	States	Actions
Exceptions to Local Blocks										
	Allow clients to resolve DNS through the firewall	none	none	53 (DNS)	*	This Firewall (self)	OPTx subnets	IPv4 TCP/ UDP	0/0 B	   
	Allow client ICMP to the firewall	none	none	*	*	This Firewall (self)	OPTx subnets	IPv4 ICMP any	0/0 B	   
Block to protected local networks										
	Reject all other traffic to the firewall	none	none	*	*	This Firewall (self)	*	IPv4 *	0/0 B	   
	Reject all other traffic to private networks	none	none	*	*	PrivateNets	*	IPv4 *	0/0 B	   
General pass rules										
	Default allow all from OPTx	none	none	*	*	*	*	IPv4 *	0/0 B	   
 Add  Add  Delete  Toggle  Copy  Save 										

Fig. 15: Example firewall rules for isolated LAN type segment

Tip: Rule separators are useful for documenting a ruleset in place.

Similar to the isolated network scenario, it is also possible to be much more strict with rules to only allow specific outbound ports. When creating this type of configuration,

2.7.7 Other Services

In most cases the above configuration is sufficient and clients on the new LAN can now obtain an address and reach the Internet. However, there may be other custom settings which need accounted for when adding a new local interface:

- If the DNS resolver has specific interface bindings, add the new interface to the list.
- If using ALTQ traffic shaping, re-run the shaper wizard to include this new LAN type interface.
- Consider using captive portal to control access the interface

2.8 Factory Reset Procedure

This procedure performs a factory reset using the hardware reset button on the Netgate 4200. This button is located on the rear side of the unit toward the left end, between the power and console connectors and under the power button. See [Input and Output Ports](#) for reference photos.

See also:

- [Factory Reset from GUI or Console](#)

Unlike some other models of Netgate hardware, the reset procedure on Netgate 4200 can be triggered while the device is running and does not require complicated timing.

1. Power on the device if it is not already running.

If the device is booting, wait for the **Diamond** LED to start flashing blue or turn solid blue.

2. **Press and hold** the reset button (bottom).

Note: This is the bottom (recessed) button and may require a pen, paperclip, or similar tool to press.

The LEDs will start to fill in red one by one (Circle, Square, then Diamond) while the button is held in the depressed state.

3. Continue holding in the button until **all** the LEDs start flashing red.

This will take approximately 8 seconds. Once the LEDs start flashing red, the factory reset is in progress and the button can be released. The device will reboot automatically.

To cancel the reset procedure, release the button at any point *before* the LEDs begin to flash red. The Diamond LED will return to a solid blue state indicating that the reset has been canceled.

4. Wait for the system to complete the reset and finish the boot process.

At the end of the boot process the LEDs will return to the ready state, with the Diamond LED solid blue.

When the device boots again it will be at its factory default settings and accessible from the LAN at <https://192.168.1.1>.

If this procedure fails, [connect to the console](#) and perform a factory reset there.

2.9 Changing the Boot Order

The appliance ships with a factory default boot order which may not be optimal for all users. Changing the boot can reduce the boot time in environments where the default is slower than expected.

Before starting, *determine the platform firmware type* (AMI or SBL).

The procedure to change the boot order differs based on the firmware type. Additionally, there is a method to change the boot order for AMI firmware from a command prompt in pfSense® Plus software.

Follow the document which matches the firmware type on the device.

2.9.1 Changing the Boot Order in AMI Firmware

Users can change the platform firmware (“firmware”) boot order for Netgate 4200 devices using AMI firmware in either a temporary way for a single boot or persistently.

Changing these settings requires local console access and downtime while making changes.

Temporary Boot Order Override

It is possible to temporarily override the AMI firmware boot order for a single boot. For example, to boot from a USB drive when installing or reinstalling pfSense® Plus software:

- *Connect to the serial console.*
- Reboot the device.
- During the boot sequence, press either the Del or Esc key when prompted to enter the firmware configuration.
- Navigate to the **Save & Exit** tab.
- Use the arrow keys to highlight an option in the **Boot Override** section.
- Press the Enter key to boot from the selected device.

Persistent Boot Order Change

Changing the boot order in the AMI firmware settings is relatively straightforward but requires rebooting the device and accessing the firmware configuration. The device will be offline during this time, so these actions must be performed from a local serial console either directly connected to a client system or by other means of out-of-band access.

To alter the boot order in this way, take the steps in the following sections.

Access the Firmware Boot Settings

The first task is to access the firmware configuration as follows:

- *Connect to the serial console.*
- Reboot the device.
- Wait for the firmware prompt to appear.
- Press either the Del or Esc key to enter the firmware configuration.
- Navigate to the **Boot** tab.

From here, make any desired changes in the **Boot Option Priorities** section, such as those in the following sections.




Fig. 16: AMI firmware Boot Override Selection

Version 2.22.1285. Copyright (C) 2024 AMI
BIOS Date: 02/01/2024 15:18:05 Ver: 2AZRT81
Press or <ESC> to enter setup.

Fig. 17: AMI Firmware Prompt




Fig. 18: AMI Firmware Boot Option Priorities

Make pfSense® Plus software boot first

To give pfSense® Plus software top priority when booting, make the following changes:

- Highlight **Boot Option #1** with the up/down arrow keys.
- Press the **Enter** key to open the device choice menu.
- Select the entry which corresponds to pfSense® Plus software using the up/down arrow keys.

This entry may be labeled **pfSense+**, **FreeBSD**, or share the name of the disk, such as **Ultra HS-COMBO**.

- Press the **Enter** key to select the device.

Disable Redundant/Unnecessary Entries

To disable unnecessary entries, such as for PXE or for operating system entries which are no longer present or needed, take the following steps:

- Highlight the first unnecessary boot option in the list with the up/down arrow keys, for example a PXE boot option.
- Press the **Enter** key to open the device choice menu.
- Select the **Disabled** option using the up/down arrow keys.
- Press the **Enter** key to select the option.
- Repeat these steps for all other PXE entries.




Fig. 19: AMI Firmware Boot Device Selection




Fig. 20: AMI Firmware Boot Device Disabled

Note: As each option is disabled, the remaining options move up in the list, so it may appear as though the change is not having any effect until several of the ports are disabled.




Fig. 21: AMI Firmware Boot Options with PXE Entries Disabled

Save and Exit the Firmware Configuration

Press the F4 key to save and exit or navigate to **Save & Exit** and choose **Save Changes and Exit**.

After the system boots, reboot it again to confirm the boot order is correct.

2.9.2 Changing the Boot Order in SBL

Users can change the SBL boot order in either a temporary way for a single boot or persistently.

Changing these settings requires local console access and downtime while making changes.

Temporary Boot Order Override

SBL has a boot manager which can temporarily override the boot device for a single boot. For example, to boot from a USB drive when installing or reinstalling pfSense® Plus software:

- *Connect to the serial console.*
- Reboot the device.
- Wait for the boot prompt to appear.
- Press F7 to enter the boot manager menu.




Fig. 22: SBL Boot Manager Menu

- Use the up/down arrow keys to highlight a device in the boot manager menu.
- Press the Enter key to boot from the selected device.

Tip: The Boot Manager is also available from within the firmware configuration. To reach it that way, press either the F2 or Down arrow key at the prompt then select **Boot Manager**.

Persistent Boot Order Change

Changing the boot order in the SBL firmware settings is relatively straightforward but requires rebooting the device and accessing the firmware configuration. The device will be offline during this time, so these actions must be performed from a local serial console either directly connected to a client system or by other means of out-of-band access.

To alter the boot order in this way, take the steps in the following sections.

Access the SBL Boot Maintenance Manager

- *Connect to the serial console.*
- Reboot the device.
- Wait for the firmware prompt to appear.




Fig. 23: SBL Firmware Prompt

- Press either the F2 or Down arrow key to enter the firmware configuration.
- Use the up/down arrow keys to select the **Boot Maintenance Manager** then press Enter.




Fig. 24: SBL Boot Maintenance Manager

- Select **Boot Options** then press Enter.

Make pfSense® Plus software boot first

- Select **Change Boot Order** then press Enter.




Fig. 25: SBL Change Boot Order

- Select **Change the order** and press Enter.
- Use the arrow keys to select the entry in the list corresponding to the disk containing pfSense® Plus software.

Note: The eMMC disk is likely named **Generic Ultra Fast Media** but can vary depending on hardware. If the device contains an M.2 NVMe SSD, the SSD should be moved to the first position in the list.

- Use the + key to move the selected entry up in the list until it reaches the top.
- Repeat selecting entries and moving them if any other changes to the order are necessary.
- Press **Enter** to finish setting the positions.




Fig. 26: Boot Order Device List

Disable Redundant/Unnecessary Entries

The **Boot Options** screen can also add or remove boot entries. For example, if the device contains an M.2 NVMe SSD, it should not boot using the eMMC disk, so the eMMC disk option can be removed.

Alternately, unwanted devices can be moved to the bottom of the boot order so they are unlikely to be used as long as other options are possible.

Save and Exit the SBL Configuration

SBL displays a notice at the bottom of the screen when there are unsaved changes pending:




Fig. 27: SBL Configuration Changed Notice

To save these changes:

- Press the F10 key.
- Press the y key to confirm.

This will save any pending changes, such as alterations to the boot order.

From this point, the device can be rebooted. Either by pressing the Esc key to exit the firmware configuration or by power cycling the device.




Fig. 28: Confirm Saving Boot Order Changes

2.9.3 Changing the Boot Order using efibootmgr (AMI Only)

The boot order can be changed by the `efibootmgr` utility on pfSense® Plus software on Netgate 4200 devices using AMI firmware.

The `efibootmgr` utility can alter the EFI boot order while pfSense® Plus software is running. This allows administrators to make changes to the boot order remotely without causing any downtime. Making the changes is more complicated than using the firmware setup method, however.

View Current Settings

The first step is to view the current boot settings by entering the `efibootmgr` command at a console or SSH shell prompt:

```
# efibootmgr
Boot to FW : false
BootCurrent: 0014
Timeout      : 3 seconds
BootOrder    : 0009, 0000, 000C, 000D, 000E, 000F, 0010, 0011, 0012, 0013, 0014, 000A
Boot0009* Fedora
Boot0000* Fedora
Boot000C* UEFI: PXE IPv4 Intel(R) Ethernet Controller I226-V
Boot000D* UEFI: PXE IPv6 Intel(R) Ethernet Controller I226-V
Boot000E* UEFI: PXE IPv4 Intel(R) Ethernet Controller I226-V
Boot000F* UEFI: PXE IPv6 Intel(R) Ethernet Controller I226-V
Boot0010* UEFI: PXE IPv4 Intel(R) Ethernet Controller I226-V
Boot0011* UEFI: PXE IPv6 Intel(R) Ethernet Controller I226-V
Boot0012* UEFI: PXE IPv4 Intel(R) Ethernet Controller I226-V
Boot0013* UEFI: PXE IPv6 Intel(R) Ethernet Controller I226-V
+Boot0014* UEFI: Generic Ultra HS-COMBO, Partition 1
Boot000A* UEFI: Built-in EFI Shell
```

Note: The example output above is from a factory default setup, which will be similar to most devices in the field unless they have been reinstalled.

The output includes several items, including a list of the current boot device and boot order.

Locate pfSense® Plus Software Entry

The next task is to locate the entry which corresponds to pfSense® Plus software. This entry may be labeled **pfSense+**, **FreeBSD**, or share the name of the disk, such as **Ultra HS-COMBO**. The ID of this entry should also match the ID listed in `BootCurrent` in the output of `efibootmgr`.

For example, in the previous example output, the current boot device is:

```
BootCurrent: 0014
```

This ID, **0014**, corresponds with the following entry in the list:

```
+Boot0014* UEFI: Generic Ultra HS-COMBO, Partition 1
```

Note: This entry is marked with a + starting the line indicating it is the current boot entry as well. The * after the ID indicates the entry is active. The Boot part of the ID should be skipped/omitted as entries are only referenced by the hexadecimal digits portion of the ID. Leading zeroes may also be omitted.

In this case, the **0014** entry is the proper target and the one which should be given priority. Keep a note of this ID as it will be required in the following sections.

Make pfSense® Plus software boot first

To give pfSense® Plus software top priority when booting, use the **-o** parameter to **efibootmgr** to set a new boot order. IDs not listed in the **-o** parameter will be deactivated.

Only Boot pfSense® Plus Software

For example, to boot only from pfSense® Plus software and ignore all others, use:

```
# efibootmgr -o 0014
```

Note: AMI firmware may automatically reactivate PXE entries in this list during boot, but they will be placed at the end, so they will not interfere.

Note: The output of **efibootmgr** may not show deactivated entries, to view all entries in the table, use **efibootmgr -v**.

Give pfSense® Plus Software Priority

Alternately, to keep the other entries but move pfSense® Plus software to the top, first look at the current Boot Order:

```
BootOrder : 0009, 0000, 000C, 000D, 000E, 000F, 0010, 0011, 0012, 0013, 0014, 000A
```

Take the current list, move the pfSense® Plus software entry ID to the start, and surround the list with quotes:

```
# efibootmgr -o "0014, 0009, 0000, 000C, 000D, 000E, 000F, 0010, 0011, 0012, 0013, 000A"
```

Instead of quotes, the IDs can also be passed without spaces:

```
# efibootmgr -o 0014,0009,0000,000C,000D,000E,000F,0010,0011,0012,0013,000A
```

Also, leading zeroes can be omitted:

```
# efibootmgr -o 14,9,0,C,D,E,F,10,11,12,13,A
```

Removing Redundant/Unnecessary Entries

There may be entries in the `efibootmgr` list which are redundant or unnecessary.

Warning: While it is possible to delete entries, there is some risk involved, so omitting the unused entries from the boot order is sufficient as the unreferenced entries are harmless.

In the example output there are two entries for operating systems which are no longer present on the disk:

```
Boot0009* Fedora
Boot0000* Fedora
```

To delete these entries, for example, use `efibootmgr -B -b <id>`:

```
# efibootmgr -B -b 0009
# efibootmgr -B -b 0000
```

Note: If the default entries are removed (e.g. PXE or USB media), the AMI firmware will add them back automatically to the end of the list, so removing them is unnecessary.

Finish Up

The changes take effect immediately so the only remaining step is to reboot the device and confirm it uses the expected boot order.

2.10 Updating the Platform Firmware

Before starting, *determine the platform firmware type* (AMI or SBL).

The procedure to update the platform firmware differs based on the firmware type.

Follow the document which matches the firmware type on the device.

2.10.1 Updating AMI Platform Firmware

Netgate may provide occasional updates to the Netgate 4200 platform firmware (“firmware”) for security fixes or other stability improvements. The firmware cannot be updated automatically, it must be updated manually. This document describes a simple method for updating the firmware using a USB mass storage device.

When this is necessary, Netgate will provide a means for owners of Netgate 4200 hardware to download the firmware files directly.

Note: This method only updates the main firmware area, it does not update the management engine or microcontroller.

Updating the firmware is relatively straightforward but requires rebooting the device and accessing the firmware configuration. The device will be offline during this time, so these actions must be performed from a local serial console either directly connected to a client system or by other means of out-of-band access.

Prepare a USB Drive

The firmware can read its update file from a DOS (FAT) formatted partition on a USB drive. USB drives can be formatted in this manner by most operating systems.

Note: Some large USB drives may not be compatible with this filesystem type. If the OS does not offer this filesystem type as a choice when formatting the USB drive, try a smaller drive or an alternate method of formatting.


Copy the firmware file, e.g. `2AZRT81.rom`, to the DOS partition on the USB drive.

Plug the USB drive into the USB port on the 4200 (*Input and Output Ports*).

Access the Firmware Configuration

The first task is to access the firmware configuration as follows:

- *Connect to the serial console.*
- Reboot the device.
- During the boot sequence, press either the `Del` or `Esc` key when prompted to enter the firmware configuration.



Version 2.22.1285. Copyright (C) 2024 AMI
BIOS Date: 02/01/2024 15:18:05 Ver: 2AZRT81
Press or <ESC> to enter setup.

Fig. 29: The Netgate 4200 AMI firmware prompt

- Navigate to the **Firmware Update** tab.

The functions on this tab will update the firmware as described in the next section.

Update the Firmware

Starting from the **Firmware Update** tab, take the following steps to update the firmware.

Choose items from the menu by using the arrow keys to select an entry and then pressing the `Enter` key to confirm the selection.

- Choose **Select Image file**.

This action will trigger a dialog prompt for a storage device.

- Select the USB device with the DOS partition.

The listed size should match the size of the drive.

This action will trigger a dialog prompt for the firmware update file.

- Select the firmware update file from the list, for example `2AZRT81.rom`.

This action will close the selection dialog and return to the **Firmware Update** tab.

- Confirm the selected image file is displayed at the top of the **Firmware Update** tab.

- Select **Update Image** to begin the firmware update.

The device will update the firmware using the selected file and display a progress meter during this process.

When the upgrade completes, the device will prompt to reset.




Fig. 30: The Netgate 4200 AMI Firmware Update Tab




Fig. 31: The Netgate 4200 AMI Firmware Update Tab




Fig. 32: Select a Storage Device for AMI Firmware Update




Fig. 33: Select an AMI Firmware Update File




Fig. 34: AMI Firmware Update tab with a Firmware Update Image File Selected




Fig. 35: AMI Firmware Update in Progress

- Reset the system by pressing a key (e.g. Enter or Space) when prompted.




Fig. 36: AMI Firmware Update Complete

After pressing a key, the device will reboot with the new firmware.

Confirm the Update

To confirm the update, enter the firmware again and check the version reported on the first screen.

- During the boot sequence, press either the Del or Esc key when prompted to enter the firmware configuration.

```
Version 2.22.1285. Copyright (C) 2024 AMI
BIOS Date: 02/01/2024 15:18:05 Ver: 2AZRT81
Press <DEL> or <ESC> to enter setup.
```

Fig. 37: The Netgate 4200 AMI Firmware Prompt

- Look at the **Project Version** line and confirm it matches the new expected value.

The exact version number will depend on the file provided by Netgate.




Fig. 38: The Netgate 4200 AMI Firmware Information Screen

2.10.2 Updating SBL Platform Firmware

Warning: The update procedure for SBL is still under development.

1. Download the firmware file for the Netgate 4200 from the [Netgate Store](#), e.g. `FwuImage.bin`
2. Copy the firmware file to a USB memstick formatted as DOS (FAT)
3. Insert the memstick into the USB port on the right side of the Netgate 4200 and boot the device
4. Wait for the boot prompt to appear
5. Press F7 to enter the boot manager menu
6. Use the up/down arrow keys to highlight **UEFI Shell**
7. Press **Enter** to boot into the **UEFI Shell**
8. Enter `fwupdate` at the prompt and press **Enter**
9. Follow the output as the update completes
10. Power off the device after the update completes
11. Remove the USB memstick
12. Power on the device and allow it to boot

Tip: After updating, a good practice is to check and confirm the correct *boot order*.

2.11 M.2 NVMe SSD Installation

The Netgate® 4200 has built-in onboard eMMC storage. Optionally, a PCIe-based M.2 NVMe drive can be installed as an upgrade or to bypass the onboard eMMC flash memory.

M.2 NVMe SSD Installation Outline

- *Warnings and Precautions*
- *Required Tools and Hardware*
- *Installation Procedure*

See also:

Netgate 4200 M.2 Expansion Socket FAQ

2.11.1 Warnings and Precautions

Danger: Anti-static protection must be used throughout this procedure.

Warning: pfSense® Plus software **must be wiped** from the onboard eMMC storage before reinstalling pfSense Plus software on the M.2 NVMe SSD. This is covered *later within the installation procedure* in this document.

For more details on why this is necessary and how to wipe the disk, see <https://docs.netgate.com/pfsense/en/latest/troubleshooting/multiple-disks.html>

Warning: The Netgate 4200 is only compatible PCIe-based M.2 NVMe storage devices. It **is not** compatible with M.2 SATA devices.

The Netgate 4200 has one socket compatible with a PCIe-based M.2 NVMe drive: Socket #3 labeled J13. This is the rear socket nearest to the I/O panel. This is an M-Key socket which accepts M.2 B+M-Key or M-Key PCIe NVMe SSDs **only**.

See *M.2 Socket Specifications and Capabilities* for more information.

Danger: Take all appropriate precautions and exercise care when handling the exposed system board and M.2 card. There are many delicate components which can be damaged during this process. **Damage caused via physical contact and electrostatic discharge while performing this installation is not covered by the warranty.**

2.11.2 Required Tools and Hardware

Installing an M.2 NVMe SSD in the Netgate 4200 requires the following tools and hardware:

- #1 Phillips screwdriver
- T10 Torx driver

- Anti-static grounding strap and anti-static mat for handling bare M.2 card and 4200 system
- 1 x PCIe-based M.2 NVMe SSD, 2280 size, B+M-key or M-key card
- 1 x M2.5-0.45 x 6mm Phillips pan head machine screw

See also:

This guide assumes a 2280 size card. Other cards may work, but require additional hardware for installation. See the following FAQ topics for details:

- [Which M.2 card sizes physically fit the sockets?](#)
- [What size retention screws do the M.2 sockets require?](#)

2.11.3 Installation Procedure

The installation procedure has many steps which are broken down into related groups in the remainder of this document. Follow all steps in the procedure carefully.

Take a Backup

If the system contains an existing configuration which should be carried over to the SSD, then the first step is to take a backup of that configuration.

If the existing configuration is not necessary, this section may be skipped.

There are numerous backup options covered in the pfSense software documentation section on [Backup and Restore](#).

For the purposes of reinstalling and restoring, the easiest method is to [take a local backup](#).

Download the Installer

Before proceeding further, download a copy of the [Netgate Installer](#) amd64 memstick image using a [Netgate Store Account](#) and write the installer to a USB memstick. For details, see [Reinstalling pfSense Plus Software](#).

Wipe the eMMC

To ensure the old installation of pfSense software on the eMMC does not interfere with the new installation of pfSense software on the SSD, the metadata on the eMMC must be wiped.

Warning: Do not skip this procedure. Failing to wipe the eMMC may result in installation failures, upgrade failures, or other unpredictable behavior from having two conflicting installations present.

1. [Connect to the serial console](#)
2. Boot the Netgate Installer
3. Choose the option to start a **Rescue Shell** when prompted
4. Follow the rest of the procedure for wiping the disks in the pfSense software documentation at <https://docs.netgate.com/pfsense/en/latest/troubleshooting/multiple-disks.html>

Note: The eMMC storage device will appear as `da1` in most cases when booting the installer via USB. When following the procedure to wipe the disks, use that device and not `da0` which is likely the installer memstick in the rescue shell.

To confirm the correct device, run the command `geom disk list` from the rescue shell. One device description will include `Ultra HS-COMBO` and that device is the eMMC storage.

After wiping the eMMC, run the command `shutdown -p now` from the rescue shell to cleanly shut down and power off the device.

Power Off and Disconnect

Installing the SSD requires removing the top of the case to expose the internal components. Before opening the case, the Netgate 4200 must be **completely** disconnected from everything. This includes power, network cables, USB cables, serial console cables, and any other cable or devices connected to the Netgate 4200.

Danger: Reminder:

- Anti-static protection must be used throughout this procedure.
- Any hardware damage incurred during this procedure is **not covered** by the hardware warranty.

1. Unplug the power cable

Danger: Wait at least **60 seconds** after unplugging power to proceed. This ensures that all phantom power has dissipated.

2. Unplug all network cables, USB cables and devices, serial console connections, etc.
3. Dismount the Netgate 4200 device if it is secured in some way (e.g. wall mount)
4. Move the Netgate 4200 to a safe work location such as an anti-static mat

Removing the Lid

The next portion of the procedure involves opening the device and removing the lid.

Danger: Reminder:

- Anti-static protection must be used throughout this procedure.
- Any hardware damage incurred during this procedure is **not covered** by the hardware warranty.

1. Remove the SIM card slot cover screw using the #1 Phillips head screwdriver.
2. Remove the SIM card slot cover.
3. Remove the SIM card slot retention screw using the #1 Phillips head screwdriver.
4. Turn the device over carefully and protect the surface to avoid damaging the vented lid of the device

Tip: An anti-static mat or similar non-marring work surface is ideal for this role.

5. Locate the four (4) T10 Torx pan head machine screws holding the plastic and rubber feet onto the chassis
6. Remove the four (4) T10 Torx pan head machine screws and washers holding the plastic and rubber feet using a T10 Torx driver.



Fig. 39: SIM card slot cover screw location




Fig. 40: SIM card slot retention screw location



Fig. 41: Foot screw locations




Fig. 42: Foot screw and washer removal

7. Remove the four (4) plastic and rubber feet.
8. Remove the four (4) long T10 Torx plas-tite threaded screws from the chassis corners using the T10 Torx driver.




Fig. 43: Plas-tite chassis screw removal

9. Turn the device so the I/O panel (“rear” of the system) is visible.
10. Using fingers, gently pry the edge of the plastic lid away from the I/O panel, starting from either corner of the device.
11. Continue gently prying the corner while starting to pull the metal base and I/O panel up and away from the lid.
12. Continue separating the lid from the chassis, gradually work around to the front of the lid where the LEDs and SIM slots are located.

Tip: At this point it may be easier to tilt the device upright on its side.

13. Gently pull the edge of the plastic lid at the front of the device away from the base only far enough for the lid to clear the LED guides and the SIM card slots.
14. Continue to work around to the other side of the chassis, pulling and separating.
The lid will fully separate from the chassis.
15. Set the lid off to the side, keeping it upright to avoid damaging the top surface.
16. Turn the chassis upright so that the system board is visible.



Fig. 44: Lid removal starting at a corner



Fig. 45: Separating the lid from the metal base



Fig. 46: Separating the lid from the LED guides

17. Set the upright system flat on its base.
18. Turn the device so the I/O panel (“rear” of the system) is visible.

Install the SSD

Now that the lid is removed, it is time to install the SSD.

Danger: Reminder:

- Anti-static protection must be used throughout this procedure.
- Any hardware damage incurred during this procedure is **not covered** by the hardware warranty.

1. Locate M.2 socket #3 labeled J13. This is the socket in which the M.2 NVMe SSD will be installed.

Note: As mentioned earlier in this document and in [Which M.2 card sockets are compatible with an M.2 PCIe NVMe SSD?](#), the Netgate 4200 is compatible with M.2 B+M-Key or M-Key PCIe NVMe SSDs **only** in socket #3 labeled J13. This is the rear socket nearest to the I/O panel.




Fig. 47: Netgate 4200 top-down internal view with M.2 socket #3 (J13) highlighted

2. Insert the M.2 card into socket #3 (J13) at an approximate 30° angle

Warning: M.2 cards are keyed. **Do not** force an M.2 card into a slot with mismatched keying.

Refer to [M.2 Edge Connector Keying](#) for a depiction of the different M.2 key types.



Fig. 48: Inserting the SSD into M.2 socket #3 (J13) at an angle

3. Gently push down the M.2 NVMe card until it reaches the retention screw hole.
4. Insert the retention screw into the standoff and tighten using the #1 Phillips head screwdriver.



Fig. 49: Fastening the M.2 NVMe card retention screw

Replacing and Fastening the Lid

With the M.2 NVMe SSD in place, the next step is to replace the lid and all the fasteners.

Danger: Reminder:

- Anti-static protection must be used throughout this procedure.
- Any hardware damage incurred during this procedure is **not covered** by the hardware warranty.

1. Align the internal groove in the lid with the edges of the I/O panel.
2. Lower the left edge of the lid onto the chassis.



Fig. 50: Aligning the left edge of the lid with the I/O panel

3. Continue lowering the lid, turning the system until the front (LED and SIM slot side) is visible.
4. Gently pry the front of the lid away from the chassis just enough to clear the LED light guides and the SIM card slots while simultaneously squeezing the lid down over the light guides and the SIM slots.
The lid should click into place over the light guides.
5. Check the rear corners of the lid to make sure the I/O panel is fully seated in the lid grooves.
6. Check the alignment of the plastic lid edges with the metal baseplate, SIM card slots, USB A opening, etc.



Fig. 51: Replacing the front part of the lid



Fig. 52: Replacing the front part of the lid over the LED guides



Fig. 53: Check the left edge of the I/O Panel



Fig. 54: Check the right edge of the I/O Panel

7. Turn the device over carefully and protect the surface to avoid damaging the lid.

Tip: An anti-static mat or similar non-marring work surface is ideal for this role.

8. Replace the four (4) long T10 Torx plas-tite threaded case screws in the holes (*Plas-tite chassis screw locations*) using the T10 Torx driver.

Danger: Use caution when replacing the plas-tite threaded case screws. **Do not cross thread or over-tighten the screws.** Over-tightening the screws can crack and permanently damage the plastic lid.




Fig. 55: Plas-tite chassis screw locations

9. Replace the plastic and rubber feet, fastening them in place with the four (4) T10 Torx machine screws and washers using the T10 Torx driver.
10. Replace the SIM card slot retention screw using the #1 Phillips screwdriver.

Warning: Use caution when replacing the SIM card slot retention screw. **Do not cross thread or overtighten the screw.**

The screw only requires a few gentle turns. Excess force can crack and permanently damage the plastic lid.

11. Replace the sim card slot cover and retention screw using the #1 Phillips screwdriver.

Warning: Use caution when replacing the SIM card cover retention screw. **Do not cross thread or overtighten the screw.**

The screw only requires a few gentle turns. Excess force can crack and permanently damage the slot cover.

Reconnect

The device is now ready to be put back into its former location.

1. Move the device back to its original location.
2. Re-mount the Netgate 4200 device if it should be secured in some way (e.g. wall mount)
3. Plug in all network cables, USB cables and devices, serial console connections, etc.
4. Insert the USB memstick containing the installation media
5. Plug in the power cable
6. Reconnect to the serial console

Reinstall pfSense Plus Software

With the device back together and ready to proceed, the next step is to reinstall pfSense Plus software to the SSD. This procedure is covered in detail in [Reinstalling pfSense Plus Software](#).

Note: If prompted to select a drive during the installation, choose the NVMe drive which will be `nd0`. The installer will typically select this drive automatically, but double check to be certain it is correct.

The eMMC drive (`da0` or `da1`) should remain **deselected** so it will not be used by the installer.

If there is no backup to restore, then no further steps are necessary. Login to the firewall and configure it as normal ([Initial Configuration](#)).

Restore the Configuration

The final step is to restore the configuration. If a configuration was *backed up earlier in this procedure*, now is the time to restore it using the GUI or one of the other methods mentioned in the pfSense software documentation section on [Backup and Restore](#).

REFERENCES

3.1 Netgate 4200 M.2 Expansion Socket FAQ

The Netgate® 4200 device contains three M.2 expansion sockets for additional devices. This FAQ covers topics related to these sockets and their use.

M.2 Expansion Socket FAQ

- *What is the purpose of the three M.2 sockets?*
- *Which M.2 card sizes physically fit the sockets?*
- *What size retention screws do the M.2 sockets require?*
- *Is the Netgate 4200 compatible with M.2 SATA devices?*
- *Which M.2 card sockets are compatible with an M.2 PCIe NVMe SSD?*
- *What is the procedure to install an M.2 PCIe NVMe SSD?*
- *Is the Netgate 4200 compatible with Wi-Fi cards?*
- *What is the purpose of the four small card slots behind the access panel on the front of the Netgate 4200?*
- *Which SIM card slots and M.2 sockets are connected for use with cellular modems?*
- *Which cellular modems are compatible with the Netgate 4200?*
- *Is the Netgate 4200 compatible with antennas for Wi-Fi or Cellular modems?*

See also:

M.2 NVMe SSD Installation

3.1.1 What is the purpose of the three M.2 sockets?

The three M.2 sockets on the Netgate 4200 are compatible with future expansion cards such as NVMe storage, 4G/5G Wireless WANs, Wi-Fi, and custom network cards.

Warning: Compatibility with specific devices varies with software. Not all devices are available or have drivers.

The basic hardware specification and capabilities of the M.2 sockets are as follows:

Table 1: M.2 Socket Specifications and Capabilities

Socket	Label	Location	Keying	Bus Types	Typical Uses
1	J14	Front	B-Key	PCIe 3.0 x1, USB 2.0/3.0	Wi-Fi, 4G/5G
2	J20	Middle	B-Key	USB 2.0, USB 3.0	Wi-Fi, 4G/5G
3	J13	Rear	M-Key	PCIe 4.0 x4, USB 2.0/3.0	B+M or M-Key NVMe

See also:

Refer to [M.2 Edge Connector Keying](#) for a depiction of the different M.2 key types.




Fig. 1: Netgate 4200 top-down internal view with M.2 socket #3 (J13) highlighted

3.1.2 Which M.2 card sizes physically fit the sockets?

The M.2 sockets on the Netgate 4200 primarily accommodate 80mm length cards, such as 2280, because 80mm cards can be installed using only a metric machine screw for retention. M.2 NVMe SSDs are commonly available in 2280 size.

There are pre-drilled holes tapped to accept M2.5-0.45 machine screws for card retention at 42, 52 and 80mm lengths, but the holes at 42 and 52mm are lower than the socket and the hole at 80mm.

Warning: Cards shorter than 80mm require a metal through-hole spacer or equivalent standoff in addition to an appropriate length retention screw. For specifications, see [the next question](#).




Fig. 2: Close-up view of M.2 socket #3 (J13) with retention screw locations marked

Tip: Shorter card sizes such as 2230 may also work using third party M.2 extender devices which increase the length of an M.2 card up to the equivalent size of a 2280 card.

3.1.3 What size retention screws do the M.2 sockets require?

80mm cards

80mm cards require a single M2.5-0.45 x 6mm Phillips pan head machine screw.

42 and 52mm cards

42 and 52mm cards require a screw **and** a through-hole spacer:

- M2.5-0.45 x 12mm Phillips pan head machine screw.
- 6.35mm / 0.25in tall metal through-hole spacer.

The spacer must have an inner diameter of 2.7mm (0.106in.) minimum and an outer diameter of 6mm (0.23in.) maximum.

3.1.4 Is the Netgate 4200 compatible with M.2 SATA devices?

No, the M.2 sockets on the Netgate 4200 **are not** compatible with SATA devices. The Netgate 4200 is only compatible with NVMe storage.

3.1.5 Which M.2 card sockets are compatible with an M.2 PCIe NVMe SSD?

The Netgate 4200 is compatible with M.2 B+M-Key or M-Key PCIe NVMe SSDs **only** in socket #3 labeled J13. This is the rear socket nearest to the I/O panel.




Fig. 3: Netgate 4200 top-down internal view with M.2 socket #3 (J13) highlighted

See also:

Refer to [M.2 Edge Connector Keying](#) for a depiction of the different M.2 key types.

3.1.6 What is the procedure to install an M.2 PCIe NVMe SSD?

To install an NVMe SSD, follow the guide located in this product manual: [M.2 NVMe SSD Installation](#).

3.1.7 Is the Netgate 4200 compatible with Wi-Fi cards?

Netgate does not sell Wi-Fi cards or offer official product assistance for WLAN hardware at this time. However, there are some Wi-Fi radios which have been documented to function with pfSense® software. These products have not necessarily been confirmed to work with the Netgate 4200.

See <https://docs.netgate.com/pfsense/en/latest/wireless/index.html> for more information about Wi-Fi compatibility in pfSense software.

3.1.8 What is the purpose of the four small card slots behind the access panel on the front of the Netgate 4200?

These are SIM card slots for possible future cellular modem use. Each of the B-Key M.2 sockets on the Netgate 4200 (sockets #1 and #2) are connected to one pair of SIM cards for a possible dual-carrier Wireless WAN solution.

3.1.9 Which SIM card slots and M.2 sockets are connected for use with cellular modems?

The front panel SIM slots are labeled in the plastic under the SIM slot cover.

Each SIM slot maps to one of two M.2 sockets in pairs and one slot is the default for each pair.

Table 2: SIM Slot Mapping

SIM Slot	M.2 Socket	Default
1A	1 (J14)	Yes
1B	1 (J14)	No
2A	2 (J20)	Yes
2B	2 (J20)	No

Warning: Compatibility with multiple SIM cards depends on the operating system and modem hardware.

3.1.10 Which cellular modems are compatible with the Netgate 4200?

Netgate does not sell cellular cards or offer official product assistance for 4G/LTE/5G connectivity at this time. However, there are some modems which have been documented to function in Netgate products. These products have not necessarily been confirmed to work with the Netgate 4200.

See <https://docs.netgate.com/pfsense/en/latest/cellular/index.html> for more information about cellular modem compatibility in pfSense software.



Fig. 4: Netgate 4200 SIM card slots and labels

3.1.11 Is the Netgate 4200 compatible with antennas for Wi-Fi or Cellular modems?

The Netgate 4200 is not supplied with antennas but the I/O panel (“rear”) of the device has four **single D** antenna mounting holes for **SMA bulkhead** connectors.

The device ships with dust cover plugs in the antenna mounting holes for protection.



Fig. 5: One of the antenna mounting holes on the I/O panel with its dust cover

3.2 Additional Resources

3.2.1 Netgate Training

Netgate training offers training courses for increasing your knowledge of pfSense® Plus products and services. Whether you need to maintain or improve the security skills of your staff or offer highly specialized assistance and improve your customer satisfaction; Netgate training has got you covered.

<https://www.netgate.com/training>

3.2.2 Resource Library

To learn more about how to use Netgate appliances and for other helpful resources, make sure to browse the Netgate Resource Library.

<https://www.netgate.com/resources>

3.2.3 Professional Services

Netgate TAC does not cover more complex tasks such as CARP configuration for redundancy on multiple firewalls or circuits, network design, and conversion from other firewalls to pfSense® Plus software. These items are offered as professional services and can be purchased and scheduled accordingly.

<https://www.netgate.com/our-services/professional-services.html>

3.2.4 Community Options

Customers who elected not to get a Netgate TAC plan, can seek assistance from the active and knowledgeable pfSense software community on the Netgate forum.

<https://forum.netgate.com/>

3.3 Warranty and Support

- One year manufacturer's warranty.
- Please contact Netgate for warranty information or view the [Product Lifecycle](#) page.
- All Specifications subject to change without notice

For support information, view [support plans](#) offered by Netgate.

See also:

For more information on how to use pfSense® Plus software, see the [pfSense Documentation](#) and [Resource Library](#).